


LOAD RATINGS IN LBS. WITH OUTRIGGERS EXTENDED												AREA OF OPERATION		
OPERATING RADIUS	LOADED BOOM ANGLE		BOOM LENGTH										DO NOT OPERATE IN THIS AREA WITHOUT OPTIONAL FRONT STABILIZER	
		27 FT		34 FT		43 FT		52 FT		61 FT		70 FT		
	5	77	36000*											
	10	66	21100*	71	17100*	75	16000*	78	15700*					
	15	54	15100*	62	14000*	68	12100*	72	11100*	75	10800*	77		9600*
	20	39	11100*	51	10100*	61	9100*	66	8600*	71	8200*	73		7300*
	25	17	7900*	40	7700*	53	7100*	61	6900*	66	6600*	69		5900*
	30			23	6500*	44	6100*	54	5600*	60	5300*	64		4900*
	35					33	4800	47	4700	54	4600*	60		4150*
	40					16	3500	38	4100	48	3900	55		3550
45							27	3250	41	3200	49	3050		
50	NOTE: STRUCTURAL STRENGTH RATINGS ON CHART ARE INDICATED WITH AN ASTERISKS (*)						9	2950	33	2800	44	2650		
55									23	2500	37	2350		
60											29	1900		
65											19	1700		
	0	7000	0	5000	0	3000	0	2400	0	2000	0	1400	BOOM RETRACT LOAD	
		450		360		260		230		200		175	STOWED JIB DEDUCTION	

JIB CAPACITIES FOR ALL BOOM LENGTHS											
VERIFY OPERATIONAL MODE SETTING ON LMI DISPLAY BEFORE LIFTING WITH JIB!											
LOADED BOOM ANGLE	35°	40°	45°	50°	55°	60°	65°	70°	75°	80°	
RETRACTED 24 FT. JIB	700	825	1000	1150	1340	1600	1900	2300	3100	4160	
EXTENDED 40 FT. JIB	520	580	650	730	810	930	1080	1400	1810	2260	

Range Diagram (27' – 70' boom)



IMPORTANT!

NEVER OPERATE ANY EQUIPMENT NEAR LIVE POWER LINES OR ELECTRICAL CONDUCTORS. SEE OPERATORS MANUAL FOR IMPORTANT SAFETY INFORMATION. NEVER USE ANY EQUIPMENT FOR ANYTHING OTHER THAN WHAT IT WAS INTENDED. ALL EQUIPMENT SHOULD ONLY BE OPERATED BY TRAINED, QUALIFIED PERSONNEL. SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE. ALWAYS CONSULT WITH CRANE MANUFACTURER BEFORE USE OR SETUP. ANY CAPACITIES OR LOAD RATINGS DISPLAYED HERE ARE FOR MARKETING PURPOSES ONLY AND MAY DIFFER FROM ACTUAL EQUIPMENT, ALWAYS CONSULT OPERATORS MANUAL AND CAPACITIES POSTED ON YOUR EQUIPMENT. BE SAFE!

