


Tel: (888) 337-BIGGE or (510) 638-8100 Web: www.bigge.com





TMS870 TTS870



Truck Mounted Hydraulic Cranes

BİGGE





Turning Radius: TMS870 - 45' 1" (13.7 m)

TTS870 - 29' 8" (9.04 m) (8 wheel)

Curb Clearance: TMS870 45' 9-9/16" (13.9 m)

TTS870 29' 8" (9.04 m)

Note: () Reference in meters.

Working Range














36 - 110 ft. (10.9 - 33.5 m) 8,500 lbs. (9.4 - 17 m) (3856 kg) **FEET** 200 190 170 160 150 140 130







DIMENSIONS ARE FOR LARGEST GROVE FURNISHED HOOK BLOCK AND HEADACHEBALL, WITH ANTI-TWO BLOCK ACTIVATED.

Superstructure specifications

Boom (Standard)

36 ft. - 110 ft. (10.9 m - 33.5 m) four section full power boom. Equipped with remote greasing lines for upper wear pad area. Maximum Tip Height: 118 ft. (35.9 m).

Folding Lattice Extension -110 ft. (33.5 m) Boom

31 ft. or 56 ft. (9.4 m or 17 m) folding lattice swingaway extension offsettable at 1.5°, 25° or 45°. Stows alongside base

Maximum Tip Height: 172 ft. (52.4 m).

*Optional Lattice Extension -110 ft. (33.5 m) Boom

31 ft. (9.4 m) lattice swingaway extension, offsettable at 1.5°, 25° or 45°. Stows alongside base boom section. Maximum Tip Height: 149 ft. (45.4 m).

*Boom (Optional)

35 ft. - 138 ft. (10.8 m - 42 m) five section full power boom. Equipped with remote greasing lines for upper wear pad area. Maximum Tip Height: 147 ft. (44.8 m).

*Folding Lattice Extension -138 ft. (42 m) Boom

31 ft. or 56 ft. (9.4 m or 17 m) folding lattice swingaway extension offsettable at 1.5°, 25° or 45°. Stows alongside the boom base section

Maximum Tip Height: 202 ft. (61.5 m).

*Optional Lattice Extension -138 ft. (42 m) Boom

31 ft. (9.4 m) lattice swingaway extension offsettable at 1.5°, 25° or 45°. Stows alongside boom base section. Maximum Tip Height: 177 ft. (10.8 m).

Boom Nose

Five nylatron, permanently lubricated sheaves mounted on heavy duty tapered roller bearings with removable pin-type rope guards. Quick reeving type boom nose. Removable auxiliary boom nose with removable pin type rope guard.

Boom Elevation

One double acting hydraulic cylinder with integral holding valve provides elevation from -3° to 80°.

Load Moment & Anti-Two Block System

Standard load moment and anti-two block system with audiovisual warning and control lever lockout. These systems provide electronic display of boom angle, length, radius, tip height, relative load moment, maximum permissible load and load indication and warning of impending two-block condition.

High visibility, all steel cab with acoustical lining and tinted safety glass throughout. Deluxe seat with armrest mounted hydraulic single axis controls. Dash panel incorporates gauges for all engine functions. Other standard features include: sliding side and rear windows, hot water heat, electric windshield wash/wipe, circulating air fan, sliding skylight with sunscreen and electric skylight wiper, fire extinguisher, cup holder.

Swing

Planetary swing with foot applied multi-disc wet brake. Spring applied, hydraulically released parking brake and plunger type, mechanical house lock operated from cab. Maximum speed: 2.0 RPM.

Counterweight

8,500 lbs. (3856 kg) total consisting of (1) 5,500 lbs. (2495 kg) section and (1) 3,000 lbs. (1361 kg) section. Hydraulic installation/removal. Optional 9,500 lbs. (4309 kg) to be used in conjunction with standard counterweight to provide 12,500 lbs. (5670 kg) or 18,000 lbs. (8165 kg) total counterweight.

Hydraulic System

Four main gear pumps with a combined capacity of 160 GPM (730.5 lpm)

Three individual valve banks.

Return line type filter with full flow by-pass protection and service indicator. Replaceable cartridge with beta rating of 5/12/16.

Remote mounted oil cooler with thermostatically controlled hydraulic motor driven fan.

Hoist specifications Main and Auxiliary Hoists -Model HO3OG-26G

Planetary reduction with integral automatic brake, electronic hoist drum rotation indicator, and hoist drum cable follower. Grooved

Maximum Permissible Line Pull:	12,920 lbs
	(5860 kg)
Rope Diameter:	3/4 in.
	(19 mm)
Rope Length:	620 ft.
	(189 m)
Maximum Rope Stowage:	1,163 ft.
	(354 m)

Maximum single line speed	Layer 1	<u>High Range</u> 372 fpm 113m/m	Low Range 191 fpm 58 m/m
	Layer 2	405 fpm 123 m/m	208 fpm 63 m/m
	Layer 3	438 fpm 134 m/m	225 fpm 69 m/m
	Layer 4	471 fpm 144 m/m	242 fpm 74 m/m
	Layer 5	504 fpm 154 m/m	258 fpm 79 m/m
Maximum single line pull	Layer 1	8,933 lbs. (4051 kg)	17,866 lbs. (8103 kg)
	Layer 2	8,210 lbs. (3723 kg)	16,421 lbs. (7447 kg)
	Layer 3	7,596 lbs. (3449 kg)	15,192 lbs. (6890 kg)
	Layer 4	7,067 lbs. (3205 kg)	14,135 lbs. (6410 kg)
	Layer 5	6,607 lbs. (2996 kg)	13,215 lbs. (5993 kg)

*Denotes optional equipment



TMS/TTS carrier specifications

TMS/TTS Chassis

Triple box section, four-axle carrier fabricated from high-strength, low alloy steel with towing and tie-down lugs.

TMS/TTS Outrigger System

Four hydraulic telescoping, two-stage, double box beam outriggers with inverted jack and integral holding valves. Quick release type outrigger floats 24 in. (610 mm) diameter. Three position setting with fully extended, intermediate (50%) extended and fully retracted capacities.

TMS/TTS Outrigger Controls
Located in the superstructure cab on left side (umbilical design) and on either side of carrier with lighted box. Require two hand operation. Crane level indicator (sight bubble) on right side console.

TMS Engine

Cummins MII 400E diesel, six cylinders, turbo-charged and after cooled, 661 cu. in. (10.8 L), 400 bhp (298 kW) (gross) @ 1800 RPM. Maximum torque: 1,350 ft. lbs. (1830 Nm) @ 1500 RPM. Equipped with engine brake and audio-visual engine distress system.

TTS Engine

Cummins MII 400E Plus diesel, six cylinders, turbo-charged and after cooled, 661 cu. in. (10.8 L), 400 bhp (298 kW) (gross) @ 1800 RPM. Maximum torque 1,450 ft. lbs. (1966 Nm) @ 1200 RPM. Equipped with engine brake and audio-visual engine distress system.

*Optional TMS/TTS Engine

Caterpillar C-12 diesel, six-cylinders, turbo-charged and air-to-air aftercooled, 732 cu. in. (12.0 L), 405 bhp (302 kW) (gross) @ 1800 RPM. Maximum torque: 1,450 ft. lbs. (1966 Nm) @ 1200 RPM. Equipped with engine brake and audio-visual engine distress

TMS/TTS Fuel Tank Capacity

(1) 100 gallons (376 L)

TMS Transmission

Roadranger 10 speeds forward, 3 reverse.

TTS Transmission

Roadranger 13 speeds forward, 2 reverse.

TMS Drive

8 x 4 x 4.

TTS Drive

8 x 4 x 8.

TMS Steering

Front axle, single circuit, mechanical steering with hydraulic power

TTS Steering

Front axle, single circuit, mechanical steering with hydraulic power assist. Rear steering controls located in the carrier cab.

TMS Axles

(2) Eaton beam-type steering axles, 84 in. (2.13 m) track. (2) Eaton single reduction drive axles, 74.46 in. (1.89 m) track. Inter-axle differential locks. Front: Rear:

TTS Axles

(2) Eaton beam-type steering axles, 84 in. (2.13 m) track. (2) Kessler single reduction drive axles, 83.38 in. Front: Rear:

(2.11 m) track. Inter-axle differential locks.

TMS Brakes

S-cam, dual air split system operating on all wheels. Spring-applied, air released parking brake acting on rear axles. Air dryer.

TTS Brakes

Dual air, split-system operating on all wheels. S-cam brakes on the front and wedge brakes on the rear. Spring-applied, air released parking brake acting on rear axles. Air dryer.

TMS/TTS Suspension

Front: Spring mounted tandem

Rear: Solid mounted tandem with equalizing beam and solid steel saddles.

TMS Tires

445/65R 22.5 Goodyear G286, tubeless, mounted

on aluminum disc wheels.

315/80R 22.5 Goodyear G286, tubeless, mounted Rear:

on aluminum disc wheels.

TTS Tires

445/65R 22.5 Goodyear G286, tubeless, Front/Rear:

mounted on aluminum disc wheels.

TMS *Optional Tires

445/65R 22.5 Bridgestone M844F, tubeless. 445/65R 22.5 Michelin XZY (WB), tubeless. 315/80R 22.5 Bridgestone M843, tubeless. Rear: 315/80R 22.5 Michelin XZY-1 tubeless

TTS *Optional Tires

445/65R 22.5 Bridgestone M844F, tubeless. 445/65R 22.5 Michelin XZY (WB), tubeless. Front/Rear:

TMS/TTS Lights

Full lighting package including turn indicators, head, tail, brake, and hazard warning lights.

TMS/TTS Cab

One man design, all steel fabricated with acoustical lining and One man design, all steel fabricated with acoustical lining and tinted safety glass throughout. Deluxe fabric covered, fully adjustable air ride seat. Complete driving controls and engine instrumentation including tilt telescope steering wheel, tachometer, speedometer, voltmeter, water temp., oil pressure, fuel level, air pressure gauge with A/V warning and engine high temp./low oil pressure A/V warning. Other standard items include hot water heater/defroster, electric windshield wash/wipe, fire extinguisher, seat belt, door lock and electric window.

TMS/TTS Electrical System

Two 12 V - maintenance free batteries. 12 V carrier driving lights, remaining systems 24 V. Battery disconnect standard equipment.

TMS/TTS Maximum Speed

55 MPH (88 kph)

TMS/TTS Gradeability (Theoretical)

TMS Gross Vehicle Weight

BASIC STANDARD MACHINE.

91,090 lbs. (41 318 kg), minus block and ball.

TTS Gross Vehicle Weight

BASIC STANDARD MACHINE.

91,606 lbs. (41 552 kg), minus block and ball.

TMS/TTS Miscellaneous Standard Equipment

Aluminum fenders with rear storage compartments (TMS only); dual rear view mirrors; electronic back-up alarm; sling/tool box; pump disconnect; tire inflation kit; air cleaner restriction indicator; block and ball stowage; and chrome package which includes

TMS/TTS Optional Equipment

- * 360° rotating beacon
- * Cab spotlight
- * Engine block heater
- * Hookblocks
- * Tool kit
- Trailing boom package
- * Aluminum outrigger pads

*Denotes optional equipment

4 Section Boom 31 ft. - 56 ft. (9.4 m - 17 m) Folding Boom Extension

*31 ft. (9.4 m) extension (erected)	4,048 lbs.	(1836 kg)
*56 ft. (17 m) extension (erected)	8,963 lbs.	(4066 kg)


^{*}Reduction of main boom capacities:

When lifting over swingaway and/or jib combinations, deduct total weight of all load handling devices reeved over main boom nose directly from swingaway or jib capacity.

NOTE: All load handling devices and boom attachments are considered part of the load and suitable allowances MUST BE MADE for their combined weights. Weights are for Grove furnished equipment.

Auxiliary Boom Nose	116 lbs.	(53 kg)
+ 70 ton, 6 sheave hookblock w/o cheekplates	1,674 lbs.	(759 kg)
+ 70 ton, 6 sheave hookblock w/cheekplates	2,010 lbs.	(912 kg)
+ 45 ton, 3 sheave hookblock w/o cheekplates	876 lbs.	(397 kg)
+ 45 ton, 3 sheave hookblock w/cheekplates	1,066 lbs.	(484 kg)
+ 15 ton, 1 sheave hookblock	380 lbs.	(173 kg)
+ 10 ton headache ball	560 lbs.	(254 kg)

+ Refer to rating plate for actual weight.



A6-829-015107

Regardless of counterweight and outrigger spread configuration, no deduct is required from the main boom charts for a stowed boom extension. However, the LMI system still monitors the effect of the stowed boom extension and will display a load value which will vary with changes in boom length and boom angle. To achieve maximum boom capacities, the boom extension must be removed from this

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load charl, operating instructions and other instructional plates must be read and understood prior to operating the crane.

TMS870/TTS870





7

W		يً		Q					
- 110 ft. 9 - 33.5 m)	12,500 lbs. (5670 kg)	1	00%	360°					
						85% D	omestic (Pounds)		
(Feet)	36	50	*60	70		80	90	100	110
10	+140,000 (68)	109,500 (75)	84,200 (78)	**56,450 (80)					
12	110,500 (64)	104,500 (72.5)	79,850 (76)	56,450 (78.5)					
15	96,800 (58.5)	91,400 (69)	73,900 (73)	56,450 (76)		56,500 (78.5)	**47,850 (80)		
20	72,000 (47)	71,850 (62)	59,600 (67.5)	56,450 (71.5)		50,950 (74.5)	41,000 (77)	40,350 (79)	**27,350 (80)
25	54,450	54,350	50,000	48,900		43,800	35,250	34,750	27,350
30	(32.5)	(55) 42,900	(62.5) 42,300	(67) 41,900		(71) 38,300	(73.5) 31,050	(76) 30,450	(78.5) 27,350
		(47) 34,750	(56.5) 34,750	(62.5) 35,850		(67) 33,900	(70.5) 27,650	(73) 27,000	(75.5) 25,300
35		(37.5)	(50)	(57.5)		(63)	(67)	(70)	(72.5)
40		27,050 (24.5)	27,750 (43)	28,600 (52)		29,600 (58.5)	24,350 (63)	24,250 (67)	22,900 (70)
45			22,150 (34.5)	23,000 (46.5)	:	23,950 (54)	22,050 (59.5)	21,900 (63.5)	20,850 (67)
50			17,900	18,850		19,750	20,050	19,950	19,100
			(23)	(39.5) 15,600		(49) 16,500	(55.5) 17,400	(60) 17,850	(64) 17,550
55				(32)		(43.5)	(51)	(56.5)	(61)
60				12,900 (21)		13,850 (37.5)	14,800 (46.5)	15,250 (53)	15,700 (57.5)
65					,	11,700 (30)	12,650 (41.5)	13,100 (49)	13,550 (54.5)
70						9,890	10,850	11,300	11,800
75						(20)	(35.5) 9,320	(44.5) 9,820	(50.5) 10,250
							(29) 7,980	(39.5) 8,520	(47) 8,980
80							(19)	(34.5)	(43)
85								7,370 (28)	7,860 (38.5)
90								6,360	6,880
95								(18.5)	(33) 6,020
									(27) 5,230
100									(18.5)
Minimum	boom angle (deg.) fo	r indicated leng	th (no load)						0
Maximum	boom length (ft.) at 0	degree boom	angle (no load)						110
NOTE: ()	Boom angles are	in degrees.							
*60 ft. bo	om length is with	inner-mid ext	ended and oute	er-mid & fly re	tracted	l .			
**This cap	acity is based on ma	ximum boom a	ngle.						
+ 12 part	s line required to	lift this capac	ity (using aux. I	boom nose).					
Boom Angle	36	50	*60	70		80	90	100	110
0	27,600 (28.3)	16,200 (42.8)	11,350 (53.1)	9,150 (62.8)		7,410 (72.8)	6,040 (82.8)	4,950 (92.8)	4,060 (102.8)
NOTE: ()	Reference radii a	re in feet.							

A6-829-015108

Regardless of counterweight and outrigger spread configuration, no deduct is required from the main boom charts for a stowed boom extension. However, the LMI system still monitors the effect of the stowed boom extension and will display a load value which will vary with changes in boom length and boom angle. To achieve maximum boom capacities, the boom extension must be removed from this crane.

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.



	0.500 lb a	الم	000/	2000				
-110 ft. 9-33.5 m)	8,500 lbs. (3855 kg)	1	00%	360°				
					8	5% Domestic (Pound	s)	
(Feet)	36	50	*60	70	80	90	100	110
10	+140,000 (68)	109,500 (75)	84,200 (78)	**56,450 (80)				
12	110,500 (64)	104,500 (72.5)	79,850 (76)	56,450 (78.5)				
15	96,800 (58.5)	91,400 (69)	73,900 (73)	56,450 (76)	56,50 (78.5			
20	72,000 (47)	71,850 (62)	59,600 (67.5)	56,450 (71.5)	50,95 (74.5	0 41,000	40,350 (79)	**27,35 (80)
25	54,450	54,350	50,000	48,900	43,80	0 35,250	34,750	27,350
	(32.5)	(55) 42,900	(62.5) 42,300	(67) 41,900	(71) 38,30		(76) 30,450	(78.5) 27,350
30		32,300	(56.5) 32,600	(62.5) 33,900	(67) 33,90	(70.5)	(73) 27,000	(75.5) 25,300
35		(37.5)	(50)	(57.5)	(63)	(67)	(70)	(72.5)
40		24,300 (24.5)	25,450 (43)	26,500 (52)	27,45 (58.5		24,250 (67)	22,900 (70)
45			20,350	21,200	22,15	0 22,050	21,900	20,850
50			(34.5) 16,300	(46.5) 17,250	(54) 18,15	0 19,100	(63.5) 19,450	(67) 19,100
			(23)	(39.5) 14,150	(49) 15.05		(60) 16,300	(64) 16,700
55				(32)	(43.5	(51)	(56.5)	(6 1)
60				11,600 (21)	12,60 (37.5		13,800 (53)	14,150 (57.5)
65				` ,	10,55 (30)	0 11,400	11,750 (49)	12,150 (54.5)
70					8,830	9,720	10,050	10,450
					(20)	(35.5) 8,300	(44.5) 8,670	(50.5) 9,060
75						(29)	(39.5)	(47)
80						7,070 (19)	7,460 (34.5)	7,850 (43)
85							6,420 (28)	6,810 (38.5)
90							5,510	5,900
							(18.5)	(33) 5,100
95								(27)
100								4,390 (18.5)
Minimum	boom angle (deg.) fo	r indicated leng	gth (no load)					0
Maximum	boom length (ft.) at 0	degree boom	angle (no load)					110
*60 ft. bo	oom length is with	inner-mid ex	tended and oute	er-mid & fly re	tracted.			
**This cap	acity is based on ma	ximum boom a	ngle.					
+ 12 part	s line required to l	ift this capac	ity (using aux. I	ooom nose).				
Boom Angle	36	50	*60	70	80	90	100	110
0	27,600	16,200	11,350	9,150	7,410		4,950	4,010
	(28.3)) Reference radii a	(42.8)	(53.1)	(62.8)	(72.8	(82.8)	(92.8)	(102.8

A6-829-013911D

Regardless of counterweight and outrigger spread configuration, no deduct is required from the main boom charts for a stowed boom extension. However, the LMI system still monitors the effect of the stowed boom extension and will display a load value which will vary with changes in boom length and boom angle. To achieve maximum boom capacities, the boom extension must be removed from this

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.



		ا ا	ŗ	44					
-110 ft.)-33.5 m)	5,500 lbs. (2495 kg)	•	100%	360°					
						85% D	omestic (Pound	s)	
(Feet)	36	50	*60	70		80	90	100	110
10	+140,000 (68)	109,500 (75)	84,200 (78)	**56,450 (80)					
12	110,500 (64)	104,500 (72.5)	79,850 (76)	56,450 (78.5)					
15	96,800 (58.5)	91,400 (69)	73,900 (73)	56,450 (76)		56,500 (78.5)	**47,850 (80)		
20	69,900 (47)	69,750 (62)	59,600 (67.5)	56,450 (71.5)		50,950 (74.5)	41,000 (77)	40,350 (79)	**27,3 (80)
25	52,750	52,650	50,000	48,900		43,800	35,250	34,750	27,35
	(32.5)	(55) 40,300	<u>(62.5)</u> <u>40,100</u>	<u>(67)</u> 41,100	3	(71) 38,300	(73.5) 31,050	(76) 30,450	(78.5 27,35
30		(47) 29,350	(56.5) 29,550	(62.5) 30,600	-	(67) 31,700	(70.5) 27,650	(73) 27,000	(78.5 25,30
35		(37.5)	(50)	(57.5)		(63)	(67)	(70)	(72.5
40		21,850 (24.5)	22,500 (43)	23,600 (52)		24,750 (58.5)	24,350 (63)	24,250 (67)	22,90 (70)
45			17,500 (34.5)	18,600 (46.5)	1	19,800 (54)	21,000 (59.5)	21,500 (63.5)	20,85 (67)
50			13,700 (23)	14,850 (39.5)	1	16,100 (49)	17,100 (55.5)	17,650 (60)	18,15
55			(23)	11,950		13,200	14,100	14,650	15,15
				(32) 9,590		(43.5) 10,900	(51) 11,750	(56.5) 12,250	(61) 12,80
60				(21)	((37.5) 9,010	(46.5) 9,870	(53) 10,350	(57.5 10,90
65						(30)	(41.5)	(49)	(54.5
70						7,380 (20)	8,290 (35.5)	8,790 (44.5)	9,300 (50.5
75							6,960 (29)	7,450 (39.5)	7,960 (47)
80							5,820	6,310	6,820
85							(19)	(34.5) 5,330	(43) 5,830
								(28) 4,470	(38.5 4,970
90								(18.5)	(33)
95									4,220 (27)
100									3,540 (18.5
Minimum	boom angle (deg.)	for indicated leng	gth (no load)						0
Maximum	n boom length (ft.) a	t 0 degree boom	angle (no load)						110
*60 ft. boo	om length is with in	ner-mid extende	d and outer-mid 8	fly retracted.					
**This cap	acity is based on m	naximum boom a	angle.						
+ 12 part	ts line required to	o lift this capac	city (using aux.	boom nose).					
Boom Angle	36	50	*60	70		80	90	100	110
0	27,600 (28.3)	16,200 (42.8)	11,350 (53.1)	8,430 (62.8)		6,570 (72.8)	5,220 (82.8)	4,010 (92.8)	3,18 (102.
) Reference radii		(00.1)	(32.0)		(. 2.0)	(02.0)	(02.0)	(102.

A6-829-013912D

Regardless of counterweight and outrigger spread configuration, no deduct is required from the main boom charts for a stowed boom extension. However, the LMI system still monitors the effect of the stowed boom extension and will display a load value which will vary with changes in boom length and boom angle. To achieve maximum boom capacities, the boom extension must be removed from this crane.

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.



				\Box					
-110 ft. 9-33.5 m)	3,000 lbs. (1361 kg)	1	100%	360°					
						85% D	omestic (Pound	s)	
(Feet)	36	50	*60	70		80	90	100	110
10	+140,000 (68)	109,500 (75)	84,200 (78)	**56,450 (80)					
12	110,500 (64)	104,500 (72.5)	79,850 (76)	56,450 (78.5)					
15	96,750 (58.5)	91,400 (69)	73,900 (73)	56,450 (76)		56,500 (78.5)	**47,850 (80)		
20	68,100 (47)	67,950 (62)	59,600 (67.5)	56,450 (71.5)	:	50,950 (74.5)	41,000 (77)	40,350 (79)	**27,350 (80)
25	51,300 (32.5)	51,250 (55)	50,000 (62.5)	48,900 (67)		43,800 (71)	35,250 (73.5)	34,750 (76)	27,350 (78.5)
30		37,950 (47)	36,750 (56.5)	37,700 (62.5)		38,300 (67)	31,050 (70.5)	30,450 (73)	27,350 (75.5)
35		27,150 (37.5)	26,950 (50)	28,000 (57.5)		29,100 (63)	27,650 (67)	27,000 (70)	25,300 (72.5)
40		20,100 (24.5)	20,500 (43)	21,450 (52)		22,500 (58.5)	23,600 (63)	24,200 (67)	22,900 (70)
45		(24.3)	16,050 (34.5)	16,900 (46.5)		17,900 (54)	18,950 (59.5)	19,450 (63.5)	19,950 (67)
50			12,750	13,600		14,500	15,500	15,900	16,350
55			(23)	(39.5) 11,000		(49) 11,900 (43.5)	(55.5) 12,850 (51)	(60) 13,250 (56.5)	(64) 13,600
60				(32) 9,000		9,880	(51) 10,750	11,100	(61) 11,450
65				(21)		(37.5) 8,210	(46.5) 9,090	(53) 9,390	(57.5) 9,700
70						(30) 6,830	(41.5) 7,690	(49) 7,960	(54.5) 8,240
75						(20)	(35.5) 6,510	(44.5) 6,750	(50.5) 7,010
80							(29) 5,510	(39.5) 5,730	(47) 5,960
85							(19)	(34.5) 4,840	(43) 5,060
90								(28) 4,070	(38.5) 4,270
95								(18.5)	(33) 3,580
									(27) 2,960
100	h (-)		uth (u.e. leeed)						(18.5)
	boom angle (deg.) fo								0
	boom length (ft.) at (110
	m length is with inne			fly retracted.					
•	acity is based on ma								
+ 12 part	s line required to I	int this capac	ity (using aux. i	ooom nose).					
Boom Angle	36	50	*60	70		80	90	100	110
0	27,600 (28.3)	16,200 (42.8)	11,000 (53.1)	7,990 (62.8)		6,110 (72.8)	4,970 (82.8)	3,650 (92.8)	2,630 (102.8)
NOTE: () Reference radii a	are in feet.							

A6-829-013948D

Regardless of counterweight and outrigger spread configuration, no deduct is required from the main boom charts for a stowed boom extension. However, the LMI system still monitors the effect of the stowed boom extension and will display a load value which will vary with changes in boom length and boom angle. To achieve maximum boom capacities, the boom extension must be removed from this crane.

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.





		ل		44				
-110 ft. 9-33.5 m)	0 lbs. (0 kg)	1	100%	360°				
					85%	Domestic (Pound	ls)	
(Feet)	36	50	*60	70	80	90	100	110
10	+140,000 (68)	109,500 (75)	84,200 (78)	**56,450 (80)				
12	110,500 (64)	104,500 (72.5)	79,850 (76)	56,450 (78.5)				
15	93,850	91,400 (69)	73,900	56,450	56,500 (78.5)	**47,850 (80)		
20	(58.5) 65,950	65,800	(73) 59,600	(76) 56,450	50,950	(80) 41,000	40,350	**27,35
25	(47) 49,650	(62) 49,550	(67.5) 49,300	(71.5) 48,900	(74.5) 43,800	(77) 35,250	(79) 34,750	(80) 27,350
25	(32.5)	34,800	(62.5) 33,900	(67) 35,350	(71) 36,500	(73.5) 31,050	(76) 30,450	(78.5) 27,350
30		(47)	(56.5)	(62.5)	(67)	(70.5)	(73)	(75.5)
35		24,500 (37.5)	25,200 (50)	26,200 (57.5)	27,200 (63)	27,650 (67)	27,000 (70)	25,300 (72.5)
40		17,900	19,050	19,950	21,000	21,950	22,350	22,750
45		(24.5)	(43) 14,550	(52) 15,500	(58.5) 16,550	(63) 17,4 0 0	(67) 17,800	(70) 18,200
			(34.5) 11,100	(46.5) 12,150	(54) 13,250	(59.5) 14,050	(63.5) 14,450	(67) 14,850
50			(23)	(39.5)	(49)	(55.5)	(60)	(64)
55				9,590 (32)	10,650 (43.5)	11,500 (51)	11,900 (56.5)	12,300 (61)
60				7,430 (21)	8,640 (37.5)	9,510 (46.5)	9,880 (53)	10,250 (57.5)
65				(=1)	6,940	7,870	8,230	8,620
					(30) 5,490	(41.5) 6,510	(49) 6,870	(54.5) 7,250
70					(20)	(35.5) 5,370	(44.5) 5,730	(50.5) 6,100
75						(29)	(39.5)	(47)
80						4,400 (19)	4,750 (34.5)	5,120 (43)
85						, ,	3,910 (28)	4,270 (38.5)
90							3,170	3,530
							(18.5)	(33) 2,890
95								(27)
100								2,310 (18.5)
Minimum	boom angle (deg.) f	or indicated leng	gth (no load)					0
Maximum	boom length (ft.) at	0 degree boom	angle (no load)					110
*60 ft. boo	om length is with inr	ner-mid extende	d and outer-mid 8	fly retracted.				
**This cap	pacity is based on m	aximum boom a	angle.					
+ 12 par	ts line required to	lift this capac	city (using aux.	boom nose).				
Boom Angle	36	50	*60	70	80	90	100	110
0	27,600 (28.3)	15,000 (42.8)	9,290 (53.1)	6,380 (62.8)	4,760 (72.8)	3,880 (82.8)	2,770 (92.8)	1,990 (102.8
NOTE: /) Reference radii			,				,

A6-829-013913D

Regardless of counterweight and outrigger spread configuration, no deduct is required from the main boom charts for a stowed boom extension. However, the LMI system still monitors the effect of the stowed boom extension and will display a load value which will vary with changes in boom length and boom angle. To achieve maximum boom capacities, the boom extension must be removed from this crane.

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.





		_		$\boxed{\mathbf{Q}}$				
36 -110 ft. 0.9-33.5 m)	8,500 lbs. (3855 kg)		50%	360°				
					SAEJ1	1289 APR81 Dor	nestic (Pounds)
(Feet)	36	50	**60	70	80	90	100	110
10	92,500 (68)	92,250 (75)	84,200 (78)	*56,450 (80)				
12	81,100 (64)	80,850 (72.5)	79,850 (76)	56,450 (78.5)				
15	67,850 (58.5)	67,650 (69)	67,500 (73)	56,450 (76)	56,500 (78.5)	*47,850 (80)		
20	47,850 (47)	46,450 (62)	43,750 (67.5)	43,300 (71.5)	42,600 (74.5)	41,000 (77)	40,350 (79)	*27,350 (80)
25	30,600 (32.5)	30,400 (55)	30,300 (62.5)	30,800 (67)	30,800 (71)	30,550 (73.5)	30,200 (76)	27,350 (78.5)
30		20,900 (47)	20,700 (56.5)	21,400 (62.5)	22,200 (67)	23,000 (70.5)	23,300 (73)	23,150 (75.5)
35		14,800 (37.5)	14,600 (50)	15,450 (57.5)	16,350 (63)	17,250 (67)	17,800 (70)	18,350 (72.5)
40		10,500 (24.5)	10,400 (43)	11,350 (52)	12,350 (58.5)	13,350 (63)	13,800 (67)	14,300 (70)
45			7,250 (34.5)	8,350 (46.5)	9,400 (54)	10,450 (59.5)	10,900 (63.5)	11,350 (67)
50			4,810 (23)	6,010 (39.5)	7,150 (49)	8,270 (55.5)	8,670 (60)	9,090 (64)
55				4,120 (32)	5,380 (43.5)	6,530 (51)	6,920 (56.5)	7,310 (61)
60				2,590 (21)	3,880 (37.5)	5,130 (46.5)	5,500 (53)	5,870 (57.5)
65					2,640 (30)	3,940 (41.5)	4,320 (49)	4,680 (54.5)
70					1,600 (20)	2,920 (35.5)	3,330 (44.5)	3,690 (50.5)
75						2,050 (29)	2,450 (39.5)	2,840 (47)
80						1,310 (19)	1,700 (34.5)	2,080 (43)
85							1,040 (28)	1,420 (38.5)
Minimum	boom angle (deg.) f	or indicated len	gth (no load)			18	27	37
Maximum	n boom length (ft.) at	0 degree boon	n angle (no load)					30
*This cap	acity is based upon	maximum obta	inable boom angle	.				
**60 ft. bo	oom length is with in	ner-mid extend	led and outer-mid	& fly retracted.				
Boom Angle	36	50	**60	70	80			
0	23,450 (28.3)	8,610 (42.8)	3,530 (53.1)	1,850 (62.8)	1,090 (72.8)			
NOTE: () Reference radii	, ,	(-3)	(-2.0)	(-2.0)			

A6-829-014188A

Regardless of counterweight and outrigger spread configuration, no deduct is required from the main boom charts for a stowed boom extension. However, the LMI system still monitors the effect of the stowed boom extension and will display a load value which will vary with changes in boom length and boom angle. To achieve maximum boom capacities, the boom extension must be removed from this

**60 ft. boom length is with inner-mid extended and outer-mid & fly retracted.

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.



				\bigcirc				
36 -110 ft. 10.9-33.5 m)	8,500 lbs. (3855 kg)		0%	360°				
					SAEJ	1289 APR81 Dor	nestic (Pounds	3)
(Feet)	36	50	**60	70	80	90	100	110
10	56,750 (68)	49,700 (75)	45,750 (78)	*44,250 (80)				
12	44,150 (64)	39,100 (72.5)	36,250 (76)	35,550 (78.5)				
15	31,850 (58.5)	28,800 (69)	26,800 (73)	26,700 (76)	26,350 (78.5)	*25,900 (80)		
20	19,150 (47)	18,500 (62)	17,350 (67.5)	17,700 (71.5)	17,850 (74.5)	17,800 (77)	17,650 (79)	*17,450 (80)
25	11,750 (32.5)	11,600 (55)	11,400 (62.5)	12,250 (67)	12,600 (71)	12,750 (73.5)	12,800 (76)	12,800 (78.5)
30		7,060 (47)	7,000 (56.5)	7,870 (62.5)	8,750 (67)	9,330 (70.5)	9,490 (73)	9,570 (75.5)
35		3,950 (37.5)	3,890 (50)	4,850 (57.5)	5,710 (63)	6,580 (67)	6,940 (70)	7,200 (72.5)
40		1,690 (24.5)	1,650 (43)	2,570 (52)	3,510 (58.5)	4,360 (63)	4,780 (67)	5,210 (70)
45		· · · ·	()		1,770 (54)	2,680 (59.5)	3,140 (63.5)	3,620 (67)
50						1,300 (55.5)	1,860 (60)	2,370 (64)
55								1,360 (61)
	boom angle (de ted length (no lo		38	47	51	54	57	59
	boom length (ft				36			
*This capa	city is based upon	maximum obta	inable boom ang	e.				
**60 ft. boo	om length is with in	nner-mid extend	led and outer-mid	& fly retracted.				
Boom Angle	36							
0	8,390 (28.3)							
NOTE: ()	(28.3) Reference radii	are in feet.						
• • • • • • • • • • • • • • • • • • • •			vtondod and a	uter-mid & fly retr	acted			

A6-829-014192A

Regardless of counterweight and outrigger spread configuration, no deduct is required from the main boom charts for a stowed boom extension. However, the LMI system still monitors the effect of the stowed boom extension and will display a load value which will vary with changes in boom length and boom angle. To achieve maximum boom capacities, the boom extension must be removed from this

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.









18,000 lbs. (8165 kg)





				85% Domes	stic (Pounds)	
	31 FT. LI	ENGTH (SWINGAWA	Y BASE)	56 FT. LENG	TH (SWINGAWAY BA	SE & FLY)
(Feet)	1.5°	25 °	45°	1.5°	25 °	45°
25	*12,900 (80)					
30	12,900 (78.5)					
35	12,900 (76.5)	8,340 (79.5)		8,220 (79.5)		
40	12,750 (74.5)	8,020 (77.5)	*6,370 (80)	8,220 (78)		
45	12,350 (72.5)	7,730 (76)	6,300 (79)	8,220 (76.5)		
50	11,500 (70.5)	7,390 (74)	6,250 (77)	8,220 (75)	*4,780 (80)	
55	10,950 (68.5)	7,130 (72)	6,190 (74.5)	8,220 (74)	4,640 (79.5)	
60	10,400 (66.5)	6,870 (69.5)	6,120 (72)	8,220 (72)	4,490 (78)	
65	9,960 (64)	6,660 (67.5)	6,090 (69.5)	8,220 (70)	4,340 (76)	*3,770 (80)
70	9,480 (61.5)	6,450 (65)	6,050 (67)	8,080 (68)	4,190 (74)	3,740 (78)
75	9,060 (59)	6,280 (62.5)	6,050 (64.5)	7,650 (66)	4,070 (72)	3,720 (76)
80	8,630 (56.5)	6,110 (60)	6,050 (62)	7,220 (64)	3,940 (70)	3,700 (73.5)
85	8,270 (54)	5,970 (57.5)	6,050 (59)	6,870 (62)	3,830 (67.5)	3,700 (71.5)
90	7,900 (51)	5,840 (54.5)	6,050 (56)	6,530 (60)	3,730 (65.5)	3,700 (69)
95	7,580 (48.5)	5,740 (51.5)		6,130 (58)	3,640 (63.5)	3,700 (66.5)
100	7,060 (45.5)	5,650 (48.5)		5,730 (55.5)	3,550 (61)	3,700 (64)
110	5,600 (38.5)	5,510 (41.5)		5,060 (51)	3,420 (56)	3,480 (59)
120	4,400 (30.5)	<u> </u>		4,510 (46)	3,320 (51)	
130	3,400 (18.5)			4,050 (40)	3,280 (45)	
140				3,190 (33.5)	2,320 (37.5)	
150				2,460 (24.5)		
Minimum boom angle (deg.) for indicated length	2	25	45	2	25	45
Maximum boom length (ft.) at 0 deg. boom angle		110			110	

*This capacity is based on maximum boom angle.

A6-829-015081

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.





36 - 110 ft. (10.9 - 33.5 m)



12,500 lbs. (5670 kg)





				85% Domes	tic (Pounds)	
	31 FT. L	ENGTH (SWINGAWA	Y BASE)	56 FT. LENG	TH (SWINGAWAY B	ASE & FLY)
(Feet)	1.5°	25 °	45°	1.5°	25°	45°
25	*12,900 (80)					
30	12,900 (78.5)					
35	12,900 (76.5)	8,340 (79.5)		8,220 (79.5)		
40	12,750 (74.5)	8,020 (77.5)	*6,370 (80)	8,220 (78)		
45	12,350 (72.5)	7,730 (76)	6,300 (79)	8,220 (76.5)		
50	11,500 (70.5)	7,390 (74)	6,250 (77)	8,220 (75)	*4,780 (80)	
55	10,950 (68.5)	7,130 (72)	6,190 (74.5)	8,220 (74)	4,640 (79.5)	
60	10,400 (66.5)	6,870 (69.5)	6,120 (72)	8,220 (72)	4,490 (78)	
65	9,960 (64)	6,660 (67.5)	6,090 (69.5)	8,220 (70)	4,340 (76)	*3,770 (80)
70	9,480 (61.5)	6,450 (65)	6,050 (67)	8,080 (68)	4,190 (74)	3,740 (78)
75	9,060 (59)	6,280 (62.5)	6,050 (64.5)	7,650 (66)	4,070 (72)	3,720 (76)
80	8,630 (56.5)	6,110 (60)	6,050 (62)	7,220 (64)	3,940 (70)	3,700 (73.5)
85	8,270 (54)	5,970 (57.5)	6,050 (59)	6,870 (62)	3,830 (67.5)	3,700 (71.5)
90	7,900 (51)	5,840 (54.5)	6,050 (56)	6,530 (60)	3,730 (65.5)	3,700 (69)
95	7,120 (48.5)	5,740 (51.5)		6,130 (58)	3,640 (63.5)	3,700 (66.5)
100	6,320 (45.5)	5,650 (48.5)		5,730 (55.5)	3,550 (61)	3,700 (64)
110	4,970 (38.5)	5,210 (41.5)		5,060 (51)	3,420 (56)	3,480 (59)
120	3,860 (30.5)	(41.3)		4,510 (46)	3,320 (51)	(33)
130	2,950			3,630	3,280	
140	(18.5)			(40) 2,850	(45) 2,320	
150				(33.5) 2,180	(37.5)	
nimum boom angle	2	25	45	(24.5)	25	45
.) for indicated length ximum boom length at 0 deg. boom angle	-	110		_	110	70

*This capacity is based on maximum boom angle.

A6-829-015082

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.









8,500 lbs. (3855 kg)





				8	35% Domest	tic (Pounds)	
	31 FT.	LENGTH (SWINGAWAY	BASE)	<u> </u>	56 FT. LENG	TH (SWINGAWAY BA	SE & FLY)
(Feet)	1.5°	25 °	45°		1.5°	25 °	45 °
25	*12,900 (80)						
30	12,900 (78.5)						
35	12,900 (76.5)	8,340 (79.5)			3,220 (79.5)		
40	12,750 (74.5)	8,020 (77.5)	*6,370 (80)		3,220 (78)		
45	12,350 (72.5)	7,730 (76)	6,300 (79)		3,220 (76.5)		
50	11,500 (70.5)	7,390 (74)	6,250 (77)		3,220 (75)	*4,780 (80)	
55	10,950 (68.5)	7,130 (72)	6,190 (74.5)		3,220 (74)	4,640 (79.5)	
60	10,400 (66.5)	6,870 (69.5)	6,120 (72)	8	3,220 (72)	4,490 (78)	
65	9,960 (64)	6,660 (67.5)	6,090 (69.5)		3,220 (70)	4,340 (76)	*3,770 (80)
70	9,480 (61.5)	6,450 (65)	6,050 (67)	8	3,080 (68)	4,190 (74)	3,740 (78)
75	9,060 (59)	6,280 (62.5)	6,050 (64.5)	7	7,650 (66)	4,070 (72)	3,720 (76)
80	8,630 (56.5)	6,110 (60)	6,050 (62)	7	7,220 (64)	3,940 (70)	3,700 (73.5)
85	7,910 (54)	5,970 (57.5)	6,050 (59)	6	6,870 (62)	3,830 (67.5)	3,700 (71.5)
90	6,950 (51)	5,840 (54.5)	6,050 (56)		6,530 (60)	3,730 (65.5)	3,700 (69)
95	6,120 (48.5)	5,740 (51.5)		E	6,130 (58)	3,640 (63.5)	3,700 (66.5)
100	5,370 (45.5)	5,650 (48.5)			5,730 (55.5)	3,550 (61)	3,700 (64)
110	4,120 (38.5)	4,360 (41.5)			4,820 (51)	3,420 (56)	3,480 (59)
120	3,090 (30.5)	,		3	3,780 (46)	3,320 (51)	
130	2,240 (18.5)			2	2,920 (40)	3,280 (45)	
140	(1010)			2	2,200 (33.5)	2,320 (37.5)	
150				1	1,580 (24.5)		
Minimum boom angle deg.) for indicated length	2	25	45	,	2	25	45
Maximum boom length ft.) at 0 deg. boom angle		110				110	

*This capacity is based on maximum boom angle.

A6-829-015083

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load charl, operating instructions and other instructional plates must be read and understood prior to operating the crane.







36 - 110 ft. (10.9 - 33.5 m)



5,500 lbs. (2495 kg)





				85% Domest	ic (Pounds)	
	31 FT. L	ENGTH (SWINGAWA			TH (SWINGAWAY B	ASE & FLY)
(Feet)	1.5°	25 °	45 °	1.5°	25 °	45 °
25	*12,900 (80)					
30	12,900 (78.5)					
35	12,900 (76.5)	8,340 (79.5)		8,220 (79.5)		
40	12,750 (74.5)	8,020 (77.5)	*6,370 (80)	8,220 (78)		
45	12,350 (72.5)	7,730 (76)	6,300 (79)	8,220 (76.5)		
50	11,500 (70.5)	7,390 (74)	6,250 (77)	8,220 (75)	*4,780 (80)	
55	10,950 (68.5)	7,130 (72)	6,190 (74.5)	8,220 (74)	4,640 (79.5)	
60	10,400 (66.5)	6,870 (69.5)	6,120 (72)	8,220 (72)	4,490 (78)	
65	9,960 (64)	6,660 (67.5)	6,090 (69.5)	8,220 (70)	4,340 (76)	*3,770 (80)
70	9,480 (61.5)	6,450 (65)	6,050 (67)	8,080 (68)	4,190 (74)	3,740 (78)
75	9,060 (59)	6,280 (62.5)	6,050 (64.5)	7,650 (66)	4,070 (72)	3,720 (76)
80	8,080 (56.5)	6,110 (60)	6,050 (62)	7,220 (64)	3,940 (70)	3,700 (73.5)
85	7,050 (54)	5,970 (57.5)	6,050 (59)	6,870 (62)	3,830 (67.5)	3,700 (71.5)
90	6,150 (51)	5,840 (54.5)	6,050 (56)	6,530 (60)	3,730 (65.5)	3,700 (69)
95	5,360 (48.5)	5,740 (51.5)		6,090 (58)	3,640 (63.5)	3,700 (66.5)
100	4,660 (45.5)	5,040 (48.5)		5,380 (55.5)	3,550 (61)	3,700 (64)
110	3,480 (38.5)	3,730 (41.5)		4,180 (51)	3,420 (56)	3,480 (59)
120	2,510 (30.5)	()		3,210 (46)	3,320 (51)	_(55)
130	1,710 (18.5)			2,390 (40)	2,780 (45)	
140	(10.0)			1,710 (33.5)	1,940 (37.5)	
150				1,130 (24.5)	· ,	
Minimum boom angle deg.) for indicated length	2	25	45	14	25	45
Maximum boom length ft.) at 0 deg. boom angle		110			110	

(ft.) at 0 deg. boom angle

*This capacity is based on maximum boom angle.

A6-829-015084

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.

18















25 30 1	1.5° 12,900 (80) 12,900	1 (SWINGAWAY BA	SE) 45°	56 FT. LENGTI 1.5°	H (SWINGAWAY BA 25°	SE & FLY)
25 *** 30 1	12,900 (80) 12,900	25 °	45°	1.5°	35 °	
25 30 1	(80) 12,900				2 3°	45 °
	(78.5)					
	12,900 (76.5)	8,340 (79.5)		8,220 (79.5)		
	12,750 (74.5)	8,020 (77.5)	*6,370 (80)	8,220 (78)		
	12,350 (72.5)	7,730 (76)	6,300 (79)	8,220 (76.5)		
	11,500 (70.5)	7,390 (74)	6,250 (77)	8,220 (75)	*4,780 (80)	
	10,950 (68.5)	7,130 (72)	6,190 (74.5)	8,220 (74)	4,640 (79.5)	
60 1	(0,400 (66.5)	6,870 (69.5)	6,120 (72)	8,220 (72)	4,490 (78)	
	9,960 (64)	6,660 (67.5)	6,090 (69.5)	8,220 (70)	4,340 (76)	*3,770 (80)
70	9,480 (61.5)	6,450 (65)	6,050 (67)	8,080 (68)	4,190 (74)	3,740 (78)
	8,450 (59)	6,280 (62.5)	6,050 (64.5)	7,650 (66)	4,070 (72)	3,720 (76)
	7,310 (56.5)	6,110 (60)	6,050 (62)	7,220 (64)	3,940 (70)	3,700 (73.5)
	6,340 (54)	5,970 (57.5)	6,050 (59)	6,870 (62)	3,830 (67.5)	3,700 (71.5)
90	5,490 (51)	5,840 (54.5)	6,050 (56)	6,220 (60)	3,730 (65.5)	3,700 (69)
	4,740 (48.5)	5,190 (51.5)		5,460 (58)	3,640 (63.5)	3,700 (66.5)
	4,070 (45.5)	4,450 (48.5)		4,790 (55.5)	3,550 (61)	3,700 (64)
110	2,950 (38.5)	3,200 (41.5)		3,650 (51)	3,420 (56)	3,480 (59)
120	2,030 (30.5)	,		2,720 (46)	3,290 (51)	
130	1,270 (18.5)			1,950 (40)	2,330 (45)	
140	,			1,300 (33.5)	1,530 (37.5)	
imum boom angle for indicated length	2	25	45	23	26	45
mum boom length t 0 deg. boom angle		110			100	

*This capacity is based on maximum boom angle.

NOTE: () Boom angles are in degrees.

A6-829-015085

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.















				85% Domest	ic (Pounds)	
	31 FT. L	ENGTH (SWINGAWA			TH (SWINGAWAY B	ASE & FLY)
(Feet)	1.5°	25 °	45 °	1.5°	25 °	45 °
25	*12,900 (80)					
30	12,900 (78.5)					
35	12,900 (76.5)	8,340 (79.5)		8,220 (79.5)		
40	12,750 (74.5)	8,020 (77.5)	*6,370 (80)	8,220 (78)		
45	12,350 (72.5)	7,730 (76)	6,300 (79)	8,220 (76.5)		
50	11,500 (70.5)	7,390 (74)	6,250 (77)	8,220 (75)	*4,780 (80)	
55	10,950 (68.5)	7,130 (72)	6,190 (74.5)	8,220 (74)	4,640 (79.5)	
60	10,400 (66.5)	6,870 (69.5)	6,120 (72)	8,220 (72)	4,490 (78)	
65	9,960 (64)	6,660 (67.5)	6,090 (69.5)	8,220 (70)	4,340 (76)	*3,770 (80)
70	8,690 (61.5)	6,450 (65)	6,050 (67)	8,080 (68)	4,190 (74)	3,740 (78)
75	7,450 (59)	6,280 (62.5)	6,050 (64.5)	7,650 (66)	4,070 (72)	3,720 (76)
80	6,390 (56.5)	6,110 (60)	6,050 (62)	7,150 (64)	3,940 (70)	3,700 (73.5)
85	5,480 (54)	5,970 (57.5)	6,050 (59)	6,220 (62)	3,830 (67.5)	3,700 (71.5)
90	4,680 (51)	5,230 (54.5)	5,400 (56)	5,410 (60)	3,730 (65.5)	3,700 (69)
95	3,980 (48.5)	4,440 (51.5)		4,710 (58)	3,640 (63.5)	3,700 (66.5)
100	3,360 (45.5)	3,740 (48.5)		4,080 (55.5)	3,550 (61)	3,700 (64)
110	2,310 (38.5)	2,560 (41.5)		3,010 (51)	3,420 (56)	3,480 (59)
120	1,450 (30.5)			2,140 (46)	2,710 (51)	
130				1,420 (40)	1,810 (45)	
140					1,040 (37.5)	
mum boom angle for indicated length	16	25	45	31	32	45
num boom length 0 deg. boom angle		100			90	

^{*}This capacity is based on maximum boom angle.

A6-829-015086

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.

20



Working Range












35-138 ft. (10.8-42.0 m)

(9.4-17 m)

8,500 lbs. (3856 kg)



TMS870/TTS870

21

Weight Reductions for Load Handling Devices

5 Section Boom 31 ft. - 56 ft. (9.4 m - 17 m) Folding Boom Extension

*31 ft. (9.4 m) extension (erected)	4,048 lbs.	(1836 kg)
*56 ft. (17 m) extension (erected)	8,941 lbs.	(4056 kg)

^{*}Reduction of main boom capacities:

When lifting over swingaway and/or jib combinations, deduct total weight of all load handling devices reeved over main boom nose directly from swingaway or jib capacity.

NOTE: All load handling devices and boom attachments are considered part of the load and suitable allowances MUST BE MADE for their combined weights. Weights are for Grove furnished equipment.

Auxiliary Boom Nose	116 lbs.	(53 kg)
+ 70 ton, 6 sheave hookblock w/o cheekplates	1,674 lbs.	(759 kg)
+ 70 ton, 6 sheave hookblock w/cheekplates	2,010 lbs.	(912 kg)
+ 45 ton, 3 sheave hookblock w/o cheekplates	876 lbs.	(397 kg)
+ 45 ton, 3 sheave hookblock w/cheekplates	1,066 lbs.	(484 kg)
+ 15 ton, 1 sheave hookblock	380 lbs.	(173 kg)
+ 10 ton headache ball	560 lbs.	(254 kg)

+ Refer to rating plate for actual weight.



				Ç	>				
5 - 138 ft. .8 - 42.0 m)	18,00 (816		100%	36	0 °				
						85% Domestic (Pounds)			
(Feet)	35	55	61	74	87	99	112	125	138
10	+140,000 (65.5)	79,100 (76)	78,450 (77.5)	*57,050 (80)					
12	110,000 (62)	79,100 (73.5)	77,500 (75.5)	57,050 (78.5)	*43,300 (80)				
15	95,800 (56)	79,100 (70)	69,850 (72.5)	51,650 (76)	43,300 (78.5)	*32,100 (80)			
20	77,250 (44.5)	70,850 (64.5)	59,850 (67.5)	44,350 (71.5)	39,550 (75)	32,100 (77.5)	30,050 (79.5)	*20,150 (80)	
25	58,500	58,200	52,200	38,750	33,800	32,100	30,050	20,150	*19,000
	(29.5)	(58) 45,850	(62) 46,200	(67.5) 34,200	(71.5) 29,200	(74.5) 30,200	(77) 27,350	(79) 19,100	(80) 18,300
30		(51)	(56.5)	(63)	(68)	(71.5)	(74.5)	(76.5)	(78.5)
35		37,100 (43.5)	37,500 (50)	29,050 (58.5)	25,800 (64)	26,600 (68.5)	24,300 (71.5)	18,100 (74)	17,650 (76.5)
40		27,050	27,500	25,150	22,900	23,450	21,600	17,250	17,000
		(34.5) 22,000	(43) 22,450	(53.5) 21,800	(60) 20,000	(65) 20,450	(69) 19,250	(72) 16,450	(74) 16,350
45		(21.5)	(35)	(48.5)	(56)	(61.5)	(66)	(69)	(72)
50			18,500 (24.5)	18,550 (42.5)	17,500 (52)	17,900 (58.5)	16,900 (63)	15,750 (66.5)	15,700 (69.5)
60			(2)	12,800	12,800	14,000	13,250	13,100	13,300
w				(28)	(42.5)	(51)	(57)	(61.5)	(65)
70					8,830 (30)	10,150 (42.5)	10,700 (50)	10,700 (56)	11,050 (60)
80						7,160	8,240	8,660	9,120
						(32) 4,800	(42.5) 5,870	(49.5) 6,700	(55) 7,380
90						(15.5)	(33.5)	(43)	(49.5)
100							4,010 (21)	4,840 (35)	5,500 (43)
110								3,340	4,000
400								(24.5)	(36) 2,760
120									(27)
130									1,720 (9.5)
Minimum	boom angle (de	g.) for indicated	length (no load)						9
Maximum	boom length (f	t.) at 0 degree bo	oom angle (no lo	ad)					125
NOTE: ()) Boom angles	are in degree	es.						
*This capa	acity is based on	maximum boo	m angle.						
+ 12 part	s line required	d to lift this ca	pacity (using	aux. boom no	se).				
Boom									
Angle	35	55	61	74	87	99	112	125	
0	26,400 (28.2)	12,500 (47.4)	10,150 (53.8)	6,240 (66.6)	3,420 (79.4)	2,440 (92.2)	1,680 (105)	1,070 (117.8)	
NOTE:	() Reference	radii are in fee	et.						
									A6-829-01

T1\T2\T3\T4	% M (ODE B							
T1	0	50	50	75	100	100	100	100	100
T2	0	25	50	75	100	100	100	100	100
Т3	0	0	0	0	0	25	50	75	100
Т4	0	0	0	0	0	25	50	75	100

Regardless of counterweight and outrigger spread configuration, no deduct is required from the main boom charts for a stowed boom extension. However, the LMI system still monitors the effect of the stowed boom extension and will display a load value which will vary with changes in boom length and boom angle. To achieve maximum boom capacities, the boom extension must be removed from this

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load charl, operating instructions and other instructional plates must be read and understood prior to operating the crane.



				Ç					
35 - 138 ft. 10.8 - 42.0 m)	12,500 (5670		100%	36	0°				
						85% Dome	estic (Pounds))	
(Feet)	35	55	61	74	87	99	112	125	138
10	+140,000 (65.5)	79,100 (76)	78,450 (77.5)	*57,050 (80)					
12	110,000 (62)	79,100 (73.5)	77,500 (75.5)	57,050 (78.5)	*43,300 (80)				
15	95,800 (56)	79,100 (70)	69,850 (72.5)	51,650 (76)	43,300 (78.5)	*32,100 (80)			
20	70,700 (44.5)	70,300 (64.5)	59,850 (67.5)	44,350 (71.5)	39,550 (75)	32,100 (77.5)	30,050 (79.5)	*20,150 (80)	
25	53,150 (29.5)	52,850 (58)	52,200 (62)	38,750 (67.5)	33,800 (71.5)	32,100 (74.5)	30,050 (77)	20,150 (79)	*19,000 (80)
30	(,	41,400 (51)	41,800 (56.5)	34,200 (63)	29,200 (68)	30,200 (71.5)	27,350 (74.5)	19,100 (76.5)	18,300 (78.5)
35		33,350 (43.5)	33,700 (50)	29,050 (58.5)	25,800 (64)	26,600 (68.5)	24,300 (71.5)	18,100 (74)	17,650 (76.5)
40		27,050 (34.5)	27,500 (43)	25,150 (53.5)	22,900 (60)	23,450 (65)	21,600 (69)	17,250 (72)	17,000 (74)
45		21,750 (21.5)	22,050 (35)	21,800 (48.5)	20,000 (56)	20,450 (61.5)	19,250 (66)	16,450 (69)	16,350 (72)
50		(21.0)	17,900 (24.5)	17,600 (42.5)	17,500 (52)	17,900 (58.5)	16,900 (63)	15,750 (66.5)	15,700 (69.5)
60			(2410)	11,200 (28)	11,450 (42.5)	12,500 (51)	13,250 (57)	13,100 (61.5)	13,300 (65)
70				(20)	7,460	8,480 (42.5)	9,520	10,550	11,050 (60)
80					(30)	5,610	(50) 6,610	(56) 7,630	8,650
90						(32) 3,480	(42.5) 4,450	(49.5) 5,440	(55) 6,430
100						(15.5)	(33.5) 2,790	(43) 3,750	(49.5) 4,720
110							(21)	(35) 2,400	(43) 3,360
120								(24.5)	(36) 2,250
130									(27) 1,330 (9.5)
Minimum	boom angle (de	g.) for indicated	length (no load)						9
Maximum	boom length (ft	.) at 0 degree be	oom angle (no lo	pad)					125
NOTE: ()	Boom angles	are in degre	es.						
*This capa	ıcity is based on	maximum boo	m angle.						
+ 12 part	s line required	I to lift this ca	pacity (using	aux. boom no	se).				
Boom Angle	35	55	61	74	87	99	112	125	
0	26,400 (28.2)	12,500 (47.4)	10,150 (53.8)	6,240 (66.6)	3,420 (79.4)	2,440 (92.2)	1,680 (105)	1,070 (117.8)	

A6-829-014915

l	T1 T2 T3 T4	% M (ODE B							
	T1	0	50	50	75	100	100	100	100	100
	T2	0	25	50	75	100	100	100	100	100
	Т3	0	0	0	0	0	25	50	75	100
	Т4	0	0	0	0	0	25	50	75	100

Regardless of counterweight and outrigger spread configuration, no deduct is required from the main boom charts for a stowed boom extension. However, the LMI system still monitors the effect of the stowed boom extension and will display a load value which will vary with changes in boom length and boom angle. To achieve maximum boom capacities, the boom extension must be removed from this

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.

				C					
35 - 138 ft. (10.8 - 42.0 m)	8,500 (385)		100%	36	0°	959/ Domo	actic (Bounda	<u> </u>	
$\bigcup \bigcup \bigcup$						85% DOME	estic (Pounds)	
(Feet)	35	55	61	74	87	99	112	125	138
10	+140,000 (65.5)	79,100 (76)	78,450 (77.5)	*57,050 (80)					
12	110,000 (62)	79,100 (73.5)	77,500 (75.5)	57,050 (78.5)	*43,300 (80)				
15	95,800	79,100 (70)	69,850	51,650	43,300	*32,100 (80)			
20	(56) 70,700	70,300	(72.5) 59,850	(76) 44,350	(78.5) 39,550	32,100	30,050	*20,150	
25	(44.5) 53,150	(64.5) 52,850	(67.5) 52,200	(71.5) 38,750	(75) 33,800	(77.5) 32,100	(79.5) 30,050	(80) 20,150	*19,000
	(29.5)	(58) 41,400	(62) 41,800	(67.5) 34,200	(71.5) 29,200	(74.5) 30,200	(79.5) 27,350	(79) 19,100	(80) 18,300
30		(51)	(56.5)	(63) 29,050	(68) 25,800	(71.5) 26,600	(74.5) 24,300	(76.5) 18,100	(78.5) 17,650
35		(43.5)	(5 0)	(58.5)	(64)	(68.5)	(71.5)	(7 4)	(76.5)
40		24,700 (34.5)	24,750 (43)	24,800 (53.5)	22,900 (60)	23,450 (65)	21,600 (69)	17,250 (72)	17,000 (74)
45		19,550 (21.5)	19,550 (35)	19,750 (48.5)	19,500 (56)	20,450 (61.5)	19,250 (66)	16,450 (69)	16,350 (72)
50		(-/	15,700	15,400	15,350	16,550 (58.5)	16,900 (63)	15,750 (66.5)	15,700
60			(24.5)	(42.5) 9,490	(52) 9,730	10,800	11,900	13,000	(69.5) 13,300
70				(28)	(42.5) 6,020	(51) 7,040	(57) 8,080	(61.5) 9,130	(65) 10,200
					(30)	(42.5) 4,390	(50) 5,390	(56) 6,400	(60) 7,430
80						(32)	(42.5)	(49.5)	(55)
90						2,420 (15.5)	3,390 (33.5)	4,370 (43)	5,370 (49.5)
100							1,840 (21)	2,800 (35)	3,770 (43)
110								1,550 (24.5)	2,510 (36)
120								(=,	1,480 (27)
Minimum	boom angle (de	g.) for indicated	length (no load)					5	10
Maximum	boom length (f	t.) at 0 degree be	oom angle (no lo	ad)				1	12
NOTE: ()	Boom angles	s are in degree	es.						
*This capa	city is based on	maximum boo	m angle.						
+ 12 part	s line required	d to lift this ca	pacity (using	aux. boom no	se).				
Boom	-								
Angle	35	55	61	74	87	99	112		
0	26,400 (28.2)	12,500 (47.4)	10,150 (53.8)	6,240 (66.6)	3,420 (79.4)	2,060 (92.2)	1,200 (105)		

A6-829-014530A

T1\T2\T3\T4	% M	ODE B							
T1	0	50	50	75	100	100	100	100	100
T2	0	25	50	75	100	100	100	100	100
Т3	0	0	0	0	0	25	50	75	100
T4	0	0	0	0	0	25	50	75	100

Regardless of counterweight and outrigger spread configuration, no deduct is required from the main boom charts for a stowed boom extension. However, the LMI system still monitors the effect of the stowed boom extension and will display a load value which will vary with changes in boom length and boom angle. To achieve maximum boom capacities, the boom extension must be removed from this crane.

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.

TMS870/TTS870 25






				Ç					
5 - 138 ft. .8 - 42.0 m)	5,500 (2495		100%	360)°				
						85% Dome	estic (Pounds))	
(Feet)	35	55	61	74	87	99	112	125	138
10	+140,000 (65.5)	79,100 (76)	78,450 (77.5)	*57,050 (80)					
12	110,000 (62)	79,100 (73.5)	77,500 (75.5)	57,050 (78.5)	*43,300 (80)				
15	95,800 (56)	79,100 (70)	69,850 (72.5)	51,650 (76)	43,300 (78.5)	*32,100 (80)			
20	68,550 (44.5)	68,150 (64.5)	59,850 (67.5)	44,350 (71.5)	39,550 (75)	32,100 (77.5)	30,050 (77)	*20,150 (80)	
25	51,450 (29.5)	51,150 (58)	51,550 (62)	38,750 (67.5)	33,800 (71.5)	32,100 (74.5)	30,050 (77)	20,150 (79)	*19,000 (80)
30		39,750 (51)	39,600 (56.5)	34,200 (63)	29,200 (68)	30,200 (71.5)	27,350 (74.5)	19,100 (76.5)	18,300 (78.5)
35		29,550 (43.5)	29,500 (50)	29,050 (58.5)	25,800 (64)	26,600 (68.5)	24,300 (71.5)	18,100 (74)	17,650 (76.5)
40		22,750 (34.5)	22,500 (43)	22,850 (53.5)	22,750 (60)	23,450 (65)	21,600 (69)	17,250 (72)	17,000 (74)
45		17,650 (21.5)	17,650 (35)	17,850 (48.5)	17,600 (56)	18,800 (61.5)	19,250 (66)	16,450 (69)	16,350 (72)
50		, ,	14,050 (24.5)	13,800 (42.5)	13,750 (52)	14,900 (58.5)	16,050 (63)	15,750 (66.5)	15,700 (69.5)
60				8,190 (28)	8,430 (42.5)	9,500 (51)	10,550 (57)	11,700 (61.5)	12,800 (65)
70				, ,	4,950 (30)	5,970 (42.5)	7,000 (50)	8,060 (56)	9,120 (60)
80						3,470 (32)	4,470 (42.5)	5,480 (49.5)	6,510 (55)
90						1,610 (15.5)	2,580 (33.5)	3,570 (43)	4,560 (49.5)
100							1,130 (21)	2,090 (35)	3,060 (43)
110									1,870 (36)
Minimum k	oom angle (de	g.) for indicated	length (no load)				20	27	33
Maximum I	ooom length (ft.) at 0 degree bo	oom angle (no lo	ad)				99	
NOTE: ()	Boom angles	are in degree	es.						
*This capa	city is based on	maximum boo	m angle.						
+ 12 parts	line required	I to lift this ca	pacity (using	aux. boom no	se).				
Boom Angle	35	55	61	74	87	99			
0	26,400 (28.2)	12,500 (47.4)	10,150 (53.8)	5,640 (66.6)	2,630 (79.4)	1,280 (92.2)			

A6-829-014533A

T1 T2 T3 T4	% M (DDE B							
T1	0	50	50	75	100	100	100	100	100
T2	0	25	50	75	100	100	100	100	100
Т3	0	0	0	0	0	25	50	75	100
T4	0	0	0	0	0	25	50	75	100

Regardless of counterweight and outrigger spread configuration, no deduct is required from the main boom charts for a stowed boom extension. However, the LMI system still monitors the effect of the stowed boom extension and will display a load value which will vary with changes in boom length and boom angle. To achieve maximum boom capacities, the boom extension must be removed from this crane.

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.




A6-829-014536A

,	T1\T2\T3\T4	%	MODE B							
	T1	0	50	50	75	100	100	100	100	100
	T2	0	25	50	75	100	100	100	100	100
	Т3	0	0	0	0	0	25	50	75	100
	T4	0	0	0	0	0	25	50	75	100

Regardless of counterweight and outrigger spread configuration, no deduct is required from the main boom charts for a stowed boom extension. However, the LMI system still monitors the effect of the stowed boom extension and will display a load value which will vary with changes in boom length and boom angle. To achieve maximum boom capacities, the boom extension must be removed from this

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane



A6-829-014539

T1\T2\T3\T4\	% N	MODE B							
T1	0	50	50	75	100	100	100	100	100
T2	0	25	50	75	100	100	100	100	100
Т3	0	0	0	0	0	25	50	75	100
T4	0	0	0	0	0	25	50	75	100

Regardless of counterweight and outrigger spread configuration, no deduct is required from the main boom charts for a stowed boom extension. However, the LMI system still monitors the effect of the stowed boom extension and will display a load value which will vary with changes in boom length and boom angle. To achieve maximum boom capacities, the boom extension must be removed from this crane.

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.











				85% Domest	tic (Pounds)	
	31 FT.	LENGTH (SWINGAWAY	BASE)	56 FT. LENG	TH (SWINGAWAY BA	ASE & FLY)
(Feet)	1.5°	25 °	45 °	1.5°	25 °	45 °
35	9,500 (79.5)					
40	9,500 (78)			*5,500 (80)		
45	9,500 (76.5)	*8,750 (80)		5,400 (79.5)		
50	9,500 (75)	7,490 (78.5)	*7,800 (80)	5,300 (78)		
60	9,110 (71.5)	7,060 (75)	6,740 (77)	5,100 (75.5)	*4,640 (80)	
70	8,450 (68.5)	6,720 (71.5)	6,460 (73.5)	4,900 (72.5)	4,430 (78)	*3,600 (80)
80	7,550 (64.5)	6,330 (68)	6,350 (69.5)	4,700 (69.5)	4,220 (74.5)	3,500 (77.5)
90	6,990 (60.5)	6,060 (64)	6,280 (65.5)	4,500 (66.5)	4,120 (71)	3,400 (74)
100	6,330 (56.5)	5,820 (60)	6,220 (61)	4,300 (63.5)	3,810 (67.5)	3,300 (70.5)
110	4,820 (52)	5,400 (55.5)	5,670 (56.5)	4,100 (59.5)	3,600 (64)	3,200 (67)
120	3,580 (47)	4,050 (50.5)	4,050 (52)	3,900 (56)	3,400 (60.5)	3,100 (63)
130	2,550 (41.5)	2,910 (45)		3,190 (52)	3,190 (56)	3,000 (58.5)
140	1,680 (35.5)	1,940 (38.5)		2,300 (47.5)	2,980 (51.5)	2,900 (53.5)
150				1,540 (42.5)	2,100 (46.5)	
160					1,300 (41)	
Minimum boom angle (deg.) for indicated length	32	32	45	40	40	45
Maximum boom length (ft.) at 0 deg. boom angle		112			99	

*This capacity is based on maximum boom angle.

MODE B A6-829-014929

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.



TMS870/TTS870

29











				85% Domes	tic (Pounds)			
	31 FT. L	ENGTH (SWINGAWA	Y BASE)	56 FT. LENG	56 FT. LENGTH (SWINGAWAY BA			
(Feet)	1.5°	25 °	45 °	1.5°	25 °	45 °		
35	9,500 (79.5)							
40	9,500 (78)			*5,500 (80)				
45	9,500 (76.5)	*8,750 (80)		5,400 (79.5)				
50	9,500 (75)	7,490 (78.5)	*7,800 (80)	5,300 (78)				
60	9,110 (71.5)	7,060 (75)	6,740 (77)	5,100 (75.5)	*4,640 (80)			
70	8,450 (68.5)	6,720 (71.5)	6,460 (73.5)	4,900 (72.5)	4,430 (78)	*3,600 (80)		
80	7,550 (64.5)	6,330 (68)	6,350 (69.5)	4,700 (69.5)	4,220 (74.5)	3,500 (77.5)		
90	6,990 (60.5)	6,060 (64)	6,280 (65.5)	4,500 (66.5)	4,120 (71)	3,400 (74)		
100	5,480 (56.5)	5,820 (60)	6,220 (61)	4,300 (63.5)	3,810 (67.5)	3,300 (70.5)		
110	4,050 (52)	4,710 (55.5)	4,820 (56.5)	4,100 (59.5)	3,600 (64)	3,200 (67)		
120	2,890 (47)	3,430 (50.5)	3,430 (52)	3,890 (56)	3,400 (60.5)	3,100 (63)		
130	1,920 (41.5)	2,370 (45)		2,850 (52)	3,190 (56)	3,000 (58.5)		
140	1,110 (35.5)	1,470 (38.5)		1,970 (47.5)	2,290 (51.5)	2,570 (53.5)		
150				1,220 (42.5)	1,390 (46.5)			
nimum boom angle) for indicated lengt	h ³⁴	38	45	42	45	47		
imum boom length t 0 deg. boom angle	ı	99			74			

^{*} This capacity is based on maximum boom angle.

A6-829-014931

MODE B

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.











8,500 lbs. (3855 kg)





					85% Domesti	ic (Pounds)	
	31 FT.	LENGTH (SWINGAWAY	BASE)	$\overline{}$	56 FT. LENG	TH (SWINGAWAY BA	ASE & FLY)
(Feet)	1.5°	25°	45 °		1.5°	25 °	45 °
35	9,500 (79.5)						
40	9,500 (78)				*5,500 (80)		
45	9,500 (76.5)	*8,750 (80)			5,400 (79.5)		
50	9,500 (75)	7,490 (78.5)	*7,800 (80)		5,300 (78)		
60	9,110 (71.5)	7,060 (75)	6,740 (77)		5,100 (75.5)	*4,640 (80)	
70	8,450 (68.5)	6,720 (71.5)	6,460 (73.5)		4,900 (72.5)	4,430 (78)	*3,600 (80)
80	7,550 (64.5)	6,330 (68)	6,350 (69.5)		4,700 (69.5)	4,220 (74.5)	3,500 (77.5)
90	6,200 (60.5)	6,060 (64)	6,280 (65.5)		4,500 (66.5)	4,120 (71)	3,400 (74)
100	4,530 (56.5)	5,330 (60)	5,580 (61)		4,300 (63.5)	3,810 (67.5)	3,300 (70.5)
110	3,200 (52)	3,860 (55.5)	3,970 (56.5)		4,100 (59.5)	3,600 (64)	3,200 (67)
120	2,120 (47)	2,660 (50.5)	2,660 (52)		3,120 (56)	3,400 (60.5)	3,100 (63)
130	1,220 (41.5)	1,660 (45)			2,150 (52)	2,640 (56)	3,000 (58.5)
140					1,320 (47.5)	1,640 (51.5)	1,920 (53.5)
Minimum boom angle (deg.) for indicated length	39	44	45		47	49	50
Maximum boom length (ft.) at 0 deg. boom angle		99				87	

*This capacity is based on maximum boom angle.

MODE B A6-829-014543A

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.







35 - 138 ft. (10.8 - 42.0 m)







	31 FT. L	ENGTH (SWINGAWAY	BASE)	03 % Domesi	ic (Pounds) GTH (SWINGAWAY B.	ASE & FLY)
(Feet)	1.5°	25 °	45 °	1.5°	25 °	45 °
35	9,500 (79.5)					
40	9,500 (78)			*5,500 (80)		
45	9,500 (76.5)	*8,750 (80)		5,400 (79.5)		
50	9,500 (75)	7,490 (78.5)	*7,800 (80)	5,300 (78)		
60	9,110 (71.5)	7,060 (75)	6,740 (77)	5,100 (75.5)	*4,640 (80)	
70	8,450 (68.5)	6,720 (71.5)	6,460 (73.5)	4,900 (72.5)	4,430 (78)	*3,600 (80)
80	7,450 (64.5)	6,330 (68)	6,350 (69.5)	4,700 (69.5)	4,220 (74.5)	3,500 (77.5)
90	5,400 (60.5)	6,060 (64)	6,280 (65.5)	4,500 (66.5)	4,120 (71)	3,400 (74)
100	3,820 (56.5)	4,390 (60)	4,870 (61)	4,300 (63.5)	3,810 (67.5)	3,300 (70.5)
110	2,560 (52)	2,980 (55.5)	3,330 (56.5)	3,660 (59.5)	3,600 (64)	3,200 (67)
120	1,540 (47)	1,830 (50.5)	2,080 (52)	2,540 (56)	3,250 (60.5)	3,100 (63)
130				1,620 (52)	2,110 (56)	2,540 (58.5)
140					1,150 (51.5)	1,430 (53.5)
Minimum boom angle (deg.) for indicated leng	ıth 44	44	45	50	51	52
Maximum boom length (ft.) at 0 deg. boom ang		74			74	

MODE B A6-829-014545

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.

32



^{*} This capacity is based on maximum boom angle.







3,000 lbs. (1361 kg)





				85% Domesti	ic (Pounds)	
	31 FT. I	LENGTH (SWINGAWA	Y BASE)	56 FT. LENG	TH (SWINGAWAY B	ASE & FLY)
(Feet)	1.5°	25 °	45 °	1.5°	25 °	45 °
35	9,500 (79.5)					
40	9,500 (78)			*5,500 (80)		
45	9,500 (76.5)	*8,750 (80)		5,400 (79.5)		
50	9,500 (75)	7,490 (78.5)	*7,800 (80)	5,300 (78)		
60	9,110 (71.5)	7,060 (75)	6,740 (77)	5,100 (75.5)	*4,640 (80)	
70	8,450 (68.5)	6,720 (71.5)	6,460 (73.5)	4,900 (72.5)	4,430 (78)	*3,600 (80)
80	6,680 (64.5)	6,330 (68)	6,350 (69.5)	4,700 (69.5)	4,220 (74.5)	3,500 (77.5)
90	4,730 (60.5)	5,490 (64)	6,140 (65.5)	4,500 (66.5)	4,120 (71)	3,400 (74)
100	3,230 (56.5)	3,790 (60)	4,280 (61)	4,300 (63.5)	3,810 (67.5)	3,300 (70.5)
110	2,030 (52)	2,450 (55.5)	2,800 (56.5)	3,130 (59.5)	3, 600 (64)	3,200 (67)
120	1,060 (47)	1,350 (50.5)	1,600 (52)	2,060 (56)	2,770 (60.5)	3,100 (63)
130				1,170 (52)	1,670 (56)	2,100 (58.5)
140						1,020 (53.5)
Minimum boom angle (deg.) for indicated lengt		47	48	52	53	54
Maximum boom length (ft.) at 0 deg. boom angle		74			61	

MODE B A6-829-014547A

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.



TMS870/TTS870

33

^{*} This capacity is based on maximum boom angle.













					85% Domesti	c (Pounds)		
	31 FT	. LENGTH (SWINGAWAY I	BASE)	- 1	56 FT. LENGTH (SWINGAWAY BASE & FLY)			
(Feet)	1.5°	25 °	45 °		1.5°	25 °	45 °	
35	9,500 (79.5)							
40	9,500 (78)				*5,500 (80)			
45	9,500 (76.5)	*8,750 (80)			5,400 (79.5)			
50	9,500 (75)	7,490 (78.5)	*7,800 (80)		5,300 (78)			
60	9,110 (71.5)	7,060 (75)	6,740 (77)		5,100 (75.5)	*4,640 (80)		
70	8,220 (68.5)	6,720 (71.5)	6,460 (73.5)		4,900 (72.5)	4,430 (78)	*3,600 (80)	
80	5,760 (64.5)	6,330 (68)	6,350 (69.5)		4,700 (69.5)	4,220 (74.5)	3,500 (77.5)	
90	3,930 (60.5)	4,690 (64)	5,330 (65.5)		4,500 (66.5)	4,120 (71)	3,400 (74)	
100	2,520 (56.5)	3,080 (60)	3,570 (61)		3,730 (63.5)	3,810 (67.5)	3,300 (70.5)	
110	1,390 (52)	1,810 (55.5)	2,160 (56.5)		2,490 (59.5)	3,450 (64)	3,200 (67)	
120			1,020 (52)		1,480 (56)	2,190 (60.5)	2,790 (63)	
130						1,140 (56)	1,570 (58.5)	
Minimum boom angle (deg.) for indicated length	50	51	52		55	55	56	
Maximum boom length (ft.) at 0 deg. boom angle		74				61		
NOTE: () Boom a	ngles are i	n degrees.						

*This capacity is based on maximum boom angle.

MODE B A6-829-014549A

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.

34













-//j° 85% Domestic (Pounds) 31 FT. LENGTH (SWINGAWAY BASE) 56 FT. LENGTH (SWINGAWAY BASE & FLY) 1.5° 1.5° 25° (Feet) 25° *11.500 30 (80) 11,500 35 (78.5)11,500 10,000 6,950 40 (77) (80) (79.5)6,780 (78.5) 11,500 9,300 *8,000 45 **(75)** (78.5)(80) 11,000 8,790 6,810 6,620 50 (73.5)(76.5)(78.5)(77) 10,050 7,960 6,490 6,290 *4,900 60 (70) (72.5)(74.5)(74) (80) 7,360 (68.5) 6,400 5,960 4,560 *3,700 (80) 9,220 70 (66) (70.5)(71) (76.5)3,520 (76.5) 8,440 6,350 (66) 5,640 (67.5) 4,230 (73) 6.900 80 (64.5) (62) 7,340 (57.5) 3,870 (69.5) 3,400 (72.5) 6,590 6,340 5,260 90 (60) (61.5) (64.5) 4,980 (60.5) 3,700 (65.5) 3,290 (68.5) 6,020 6,250 6.320 100 (53) (55) (56.5)5,050 5,260 4,650 3,190 110 (47.5) (50) (51) (56.5)(61.5)(64) 3,290 (57.5) 3,280 3,690 4,070 3,110 120 (41.5)(44) (52) (59.5)3,020 (47.5) 3,120 (52.5) 2,250 2,540 3,040 130 (34.5)(36.5)(54) 1,380 2,140 2,750 140 (42.5) (26) (47.5)1,840 (41) 1.380 150 (36.5)Minimum boom angle (deg.) for indicated length 25 45 35 37 45 Maximum boom length (ft.) at 0 deg. boom angle 112 99

*This capacity is based on maximum boom angle.

MODE B A6-829-014930

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load charl, operating instructions and other instructional plates must be read and understood prior to operating the crane.



TMS870/TTS870



35











					85% Domesti	c (Pounds)	
	31 FT.	LENGTH (SWINGAWAY	BASE)	1	56 FT. LENG	TH (SWINGAWAY BA	SE & FLY)
(Feet)	1.5°	25 °	45 °		1.5°	25 °	45°
30	*11,500 (80)						
35	11,500 (78.5)						
40	11,500 (77)	*10,000 (80)			6,950 (79.5)		
45	11,500 (75)	9,300 (78.5)	*8,000 (80)		6,780 (78.5)		
50	11,000 (73.5)	8,790 (76.5)	6,810 (78.5)		6,620 (77)		
60	10,050 (70)	7,960 (72.5)	6,490 (74.5)		6,290 (74)	*4,900 (80)	
70	9,220 (66)	7,360 (68.5)	6,400 (70.5)		5,960 (71)	4,560 (76.5)	*3,700 (80)
80	8,440 (62)	6,900 (64.5)	6,350 (66)		5,640 (67.5)	4,230 (73)	3,520 (76.5)
90	6,850 (57.5)	6,590 (60)	6,340 (61.5)		5,260 (64.5)	3,870 (69.5)	3,400 (72.5)
100	5,090 (53)	5,490 (55)	6,060 (56.5)		4,980 (60.5)	3,700 (65.5)	3,290 (68.5)
110	3,690 (47.5)	3,940 (50)	4,310 (51)		4,650 (56.5)	3,480 (61.5)	3,190 (64)
120	2,540 (41.5)	2,670 (44)			3,620 (52)	3,290 (57.5)	3,110 (59.5)
130	1,600 (34.5)	1,620 (36.5)			2,620 (47.5)	3,110 (52.5)	3,040 (54)
140					1,770 (42.5)	2,130 (47.5)	
150					1,050 (36.5)	1,290 (41)	
Minimum boom angle (deg.) for indicated length	33	33	45		36	40	46
Maximum boom length (ft.) at 0 deg. boom angle		99				74	

*This capacity is based on maximum boom angle.

MODE B A6-829-014932

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.

36





35 - 125 ft. (10.8 - 38.1 m)



8,500 lbs. (3855 kg)





					85% Domesti	c (Pounds)	
	31 FT. I	LENGTH (SWINGAWAY	(BASE)	\top	56 FT. LENG	TH (SWINGAWAY BA	ASE & FLY)
(Feet)	1.5°	25 °	45 °		1.5°	25 °	45 °
30	*11,500 (80)						
35	11,500 (78.5)						
40	11,500 (77)	*10,000 (80)			6,950 (79.5)		
45	11,500 (75)	9,300 (78.5)	*8,000 (80)		6,780 (78.5)		
50	11,000 (73.5)	8,790 (76.5)	6,810 (78.5)		6,620 (77)		
60	10,050 (70)	7,960 (72.5)	6,490 (74.5)		6,290 (74)	*4,900 (80)	
70	9,220 (66)	7,360 (68.5)	6,400 (70.5)		5,960 (71)	4,560 (76.5)	*3,700 (80)
80	7,910 (62)	6,900 (64.5)	6,350 (66)		5,640 (67.5)	4,230 (73)	3,520 (76.5)
90	5,790 (57.5)	6,380 (60)	6,340 (61.5)		5,260 (64.5)	3,870 (69.5)	3,400 (72.5)
100	4,140 (53)	4,550 (55)	5,110 (56.5)		4,980 (60.5)	3,700 (65.5)	3,290 (68.5)
110	2,840 (47.5)	3,090 (50)	3,460 (51)		4,060 (56.5)	3,480 (61.5)	3,190 (64)
120	1,770 (41.5)	1,900 (44)			2,860 (52)	3,290 (57.5)	3,110 (59.5)
130					1,860 (47.5)	2,380 (52.5)	2,830 (54)
140					1,020 (42.5)	1,430 (47.5)	
Minimum boom angle eg.) for indicated length	37	39	46		42	46	47
laximum boom length .) at 0 deg. boom angle		99				87	
NOTE: () Boom ar	ngles are in o	degrees.					

^{*}This capacity is based on maximum boom angle.

MODE B A6-829-014542

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.



TMS870/TTS870

37

			(C)				
- 138 ft. 3 - 42.0 m)	8,500 lbs. (3855 kg)	100%	360				
					85% Domestic (Pe	ounds)	
(Feet)	35	61	74	87	99	112	138
10	+140,000 (65.5)	42,900 (77.5)	*32,100 (80)				
12	110,000 (62)	42,000 (75.5)	32,100 (78.5)	*31,850 (80)			
15	95,800 (56)	36,550 (72.5)	32,100 (76)	31,850 (78.5)	*21,350 (80)		
20	70,700 (44.5)	29,400 (67.5)	31,350 (71.5)	28,850 (75)	21,350 (77.5)	19,000 (79.5)	
25	53,150 (29.5)	24,350 (62)	26,450 (67.5)	25,050 (71.5)	20,850 (74.5)	18,150 (77)	*19,000 (80)
30	(20.0)	20,500	22,300	21,550	18,650	17,300	18,300
35		(56.5) 17,450	(63) 19,100	(68) 18,500	(71.5) 16,900	(74.5) 16,450	(78.5) 17,650
40		(50) 15,050	(58.5) 16,500	(64) 16,000	(68.5) 15,300	(71.5) 15,650	(76.5) 17,000
		(43) 13,100	(53.5) 14,450	(60) 14,000	(65) 13,6 5 0	(69) 14,150	(74) 16,350
45		(35) 11,450	(48.5) 12,750	(56) 12,350	(61.5) 12,100	(66) 12,700	(72) 15,700
50		(24.5)	(42.5) 10,050	(52) 9,780	(58.5) 9,580	(63) 10,150	(69.5) 13,300
60			(28)	(42.5)	(51)	(57)	(65)
70				7,860 (30)	7,710 (42.5)	8,220 (50)	10,200 (60)
80					6,270 (32)	6,730 (42.5)	7,430 (55)
90					4,800 (15.5)	5,550 (33.5)	5,370 (49.5)
100						4,010 (21)	3,770 (43)
110							2,510 (36)
120							1,480 (27)
Minimum bo	oom angle (deg.) for i	ndicated length (no	load)			0	10
Maximum b	oom length (ft.) at 0 d	egree boom angle ((no load)			•	112
NOTE: () E	Boom angles are in	degrees.					
*This capaci	ity is based on maxin	num boom angle.					
+ 12 parts	line required to life	this capacity (us	sing aux. boom no	ose).			
Boom Angle	35	61	74	87	99	112	
0	26,400 (28.2)	10,150 (53.8)	6,240 (66.6)	3,420 (79.4)	2,440 (92.2)	1,680 (105)	
NOTE: () R	Reference radii are	in feet.					
							A6-829-014

T1 T2 T3 T4 %	MODE	Α					
T1	0	0	0	0	0	0	100
T2	0	100	100	100	100	100	100
тз	0	0	25	50	75	100	100
T4	0	0	25	50	75	100	100

Regardless of counterweight and outrigger spread configuration, no deduct is required from the main boom charts for a stowed boom extension. However, the LMI system still monitors the effect of the stowed boom extension and will display a load value which will vary with changes in boom length and boom angle. To achieve maximum boom capacities, the boom extension must be removed from this crane.

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.

			Q				
- 138 ft. 3 - 42.0 m)	5,500 lbs. (2495 kg)	100%	360°				
					85% Domestic (Po	ounds)	
(Feet)	35	61	74	87	99	112	138
10	+140,000 (65.5)	42,900 (77.5)	*32,100 (80)				
12	110,000 (62)	42,000 (75.5)	32,100 (78.5)	*31,850 (80)			
15	95,800 (56)	36,550	32,100	31,850 (78.5)	*21,350 (80)		
20	68,550	(72.5) 29,400	(76) 31,350	28,850	21,350	19,000	
	(44.5) 51,450	(67.5) 24,350	(71.5) 26,450	(75) 25,050	(77.5) 20,850	(79.5) 18,150	*19,000
25	(29.5)	(62)	(6 7. 5)	(71.5)	(74.5)	(7 7)	(80)
30		20,500 (56.5)	22,300 (63)	21,550 (68)	18,650 (71.5)	17,300 (74.5)	18,300 (78.5)
35		17,450	19,100	18,500	16,900	16,450	17,650
40		(50) 15,050	(58.5) 16,500	(64) 16,000	(68.5) 15,300	(71.5) 15,650	(76.5) 17,000
40		(43)	(53.5)	(60)	(65)	(69)	(74)
45		13,100 (35)	14,450 (48.5)	14,000 (56)	13,650 (61.5)	14,150 (66)	16,350 (72)
50		11,450 (24.5)	12,750 (42.5)	12,350 (52)	12,100 (58.5)	12,700 (63)	15,700 (69.5)
60		(24.3)	10,050	9,780	9,580	10,150	12,800
			(28)	(42.5) 7,830	(51) 7,710	(57) 8,220	(65) 9,120
70				(30)	(42.5)	(50)	(60)
80					6,270 (32)	6,730 (42.5)	6,510 (55)
90					4,040	5,110	4,560
					(15.5)	(33.5) 3,340	(49.5) 3,060
100						(21)	(43)
110							1,870 (36)
Minimum b	ooom angle (deg.) for	indicated length (no	load)			0	33
Maximum I	boom length (ft.) at 0 o	legree boom angle (no load)				112
NOTE: ()	Boom angles are i	n degrees.					
*This capa	city is based on maxir	num boom angle.					
+ 12 parts	line required to lif	t this capacity (us	sing aux. boom n	ose).			
Boom							
Angle	35	61	74	87	99	112	
0	26,400 (28.2)	10,150 (53.8)	6,240 (66.6)	3,420 (79.4)	2,440 (92.2)	1,680 (105)	
NOTE: ()	Reference radii are	e in feet.					
							A6-829-014
T2\T3\T4\°(%	MODE A						

ı	T1\T2\T3\T4\\ %	MODE	Α					
	T1	0	0	0	0	0	0	100
	T2	0	100	100	100	100	100	100
	Т3	0	0	25	50	75	100	100
	Т4	0	0	25	50	75	100	100

Regardless of counterweight and outrigger spread configuration, no deduct is required from the main boom charts for a stowed boom extension. However, the LMI system still monitors the effect of the stowed boom extension and will display a load value which will vary with changes in boom length and boom angle. To achieve maximum boom capacities, the boom extension must be removed from this

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.

- 138 ft.	3 000 lbs	100%	360	<u>)</u>			
3 - 42.0 m)	3,000 lbs. (1361 kg)	100%	300		050/ Davidatio (D	da\	
\bigcup					85% Domestic (Po	bunas)	
(Feet)	35	61	74	87	99	112	138
10	+140,000 (65.5)	42,900 (77.5)	*32,100 (80)				
12	110,000 (62)	42,000	32,100 (78.5)	*31,850 (80)			
15	95,350	(75.5) 36,550	32,100	31,850	*21,350		
	(56) 66,750	(72.5) 29,400	(76) 31,350	(78.5) 28,850	(80) 21,350	19,000	
20	(44.5)	(67.5)	(71.5)	(75)	(77.5)	(79.5)	
25	50,050 (29.5)	24,350 (62)	26,450 (67.5)	25,050 (71.5)	20,850 (74.5)	18,150 (77)	*19,000 (80)
30	_(20.0)	20,500	22,300	21,550	18,650	17,300	18,300
		(56.5) 17,450	(63) 19,100	(68) 18,500	(71.5) 16,900	(74.5) 16,450	(78.5) 17,650
35		(50)	(58.5)	(64)	(68.5)	(71.5)	(76.5)
40		15,050 (43)	16,500 (53.5)	16,000 (60)	15,300 (65)	15,650 (69)	17,000 (74)
45		13,100 (35)	14,450 (48.5)	14,000 (56)	13,650 (61.5)	14,150 (66)	16,350 (72)
50		11,450	12,750	12,350	12,100	12,700	15,700
		(24.5)	(42.5) 10,050	(52) 9,780	(58.5) 9,580	(63) 10,150	(69.5) 11,700
60			(28)	(42.5)	(51)	(57)	(65)
70				6,990 (30)	7,710 (42.5)	8,220 (50)	8,220 (60)
80					5,580 (32)	6,660 (42.5)	5,740 (55)
90					3,410	4,480	3,900
					(15.5)	(33.5) 2,770	(49.5) 2,470
100						(21)	(43)
110							1,340 (36)
Minimum b	oom angle (deg.) for i	ndicated length (no	load)			0	35
Maximum b	oom length (ft.) at 0 d	legree boom angle (no load)				112
NOTE: ()	Boom angles are i	n degrees.					
*This capac	ity is based on maxin	num boom angle.					
+ 12 parts	line required to lif	t this capacity (u	sing aux. boom n	ose).			
Boom							
Angle	35	61	74	87	99	112	
0	26,400 (28.2)	10,150 (53.8)	6,240 (66.6)	3,420 (79.4)	2,440 (92.2)	1,680 (105)	

A6-829-014470A

T1 T2 T3 T4 %	MODE	Α					
T1	0	0	0	0	0	0	100
T2	0	100	100	100	100	100	100
Т3	0	0	25	50	7 5	100	100
Т4	0	0	25	50	75	100	100

Regardless of counterweight and outrigger spread configuration, no deduct is required from the main boom charts for a stowed boom extension. However, the LMI system still monitors the effect of the stowed boom extension and will display a load value which will vary with changes in boom length and boom angle. To achieve maximum boom capacities, the boom extension must be removed from this crane.

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.

138 ft.	0 lbs.	100%					
138 ft. - 42.0 m)	(0 kg)	100%	o ·	360°			
					85% Domestic (Pounds)	
(Feet)	35	61	74	87	99	112	138
10	139,500 (65.5)	42,900 (77.5)	*32,100 (80)				
12	110,000 (62)	42,000 (75.5)	32,100 (78.5)	*31,850 (80)			
15	92,450 (56)	36,550 (72.5)	32,100 (76)	31,850 (78.5)	*21,350 (80)		
20	64,600 (44.5)	29,400 (67.5)	31,350 (71.5)	28,850 (75)	21,350 (77.5)	19,000 (79.5)	
25	48,350 (29.5)	24,350 (62)	26,450 (67.5)	25,050 (71.5)	20,850 (74.5)	18,150 (77)	*19,000 (80)
30		20,500 (56.5)	22,300 (63)	21,550 (68)	18,650 (71.5)	17,300 (74.5)	18,300 (78.5)
35		17,450 (50)	19,100 (58.5)	18,500 (64)	16,900 (68.5)	16,450 (71.5)	17,650 (76.5)
40		15,050 (43)	16,500 (53.5)	16,000 (60)	15,300 (65)	15,650 (69)	17,000 (74)
45		13,100 (35)	14,450 (48.5)	14,000 (56)	13,650 (61.5)	14,150 (66)	16,350 (72)
50		11,450 (24.5)	12,750 (42.5)	12,350 (52)	12,100 (58.5)	12,700 (63)	15,450 (69.5)
60			9,160 (28)	9,710 (42.5)	9,580 (51)	10,150 (57)	10,400 (65)
70				5,990 (30)	7,430 (42.5)	8,220 (50)	7,140 (60)
80					4,720 (32)	5,790 (42.5)	4,820 (55)
90					2,550 (15.5)	3,700 (33.5)	3,100 (49.5)
100						1,990 (21)	1,760 (43)
Minimum	boom angle (deg.) fo	or indicated length	(no load)			0	40
Maximum	boom length (ft.) at (0 degree boom ano	gle (no load)				112
NOTE: ()	Boom angles are	in degrees.					
*This capa	city is based on max	dimum boom angle	<u>.</u>				
Boom Angle	35	61	74	87	99	112	
_	26,400	10,150	6,240	3,330	2,130	1,260	
0	(28.2)	(53.8)	(66.6)	(79.4)	(92.2)	(105)	

A6-829-014471

E	<u>T1\T2\T3\T4\</u> %	MODI	E A					
	T1	0	0	0	0	0	0	100
	T2	0	100	100	100	100	100	100
	Т3	0	0	25	50	75	100	100
	Т4	0	0	25	50	75	100	100

Regardless of counterweight and outrigger spread configuration, no deduct is required from the main boom charts for a stowed boom extension. However, the LMI system still monitors the effect of the stowed boom extension and will display a load value which will vary with changes in boom length and boom angle. To achieve maximum boom capacities, the boom extension must be removed from this crane.

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.





TMS870 4 SECTION BOOM

Machine equipped as follows:

110 ft. full power 4 section boom 31 - 56 ft. (9.4 - 17 m) folding swingaway Main and auxiliary hoist w/rope Auxiliary boom nose Full fuel and hydraulics 445/65R22.5 front tires 315/80R22.5 rear tires 45 ton hook block (on carrier deck) 10 ton ball (on carrier deck) Counterweight configuration-see chart

AXLE/TIRE CAPACITY	FRONT	REAR	GVW
	49,200 lbs.	60,000 lbs.	109,200 lbs.
	(22 317 kg)	(27 216 kg)	(49 533 kg)

Counterweight placement effects:

8,500 lbs. (3856 kg) cwt.	34,955 lbs.	57,525 lbs.	92,480 lbs.
on superstructure	(15 856 kg)	(26 093 kg)	(41 949 kg)
8,500 lbs. (3856 kg) cwt.	46,450 lbs.	46,030 lbs.	92,480 lbs.
on carrier	(21 070 kg)	(20 879 kg)	(41 949 kg)
3,000 lbs. (1361 kg) on S/S	42,393 lbs.	50,087 lbs.	92,480 lbs.
5,500 lbs. (2495 kg) on carrier	(19 229 kg)	(22 719 kg)	(41 949 kg)
5,500 lbs. (2495 kg) on S/S	39,012 lbs.	53,468 lbs.	92,480 lbs.
3,000 lbs. (1361 kg) on carrier	(17 696 kg)	(24 253 kg)	(41 949 kg)
5,500 lbs. (2495 kg) ONLY	36,308 lbs.	53,172 lbs.	89,480 lbs.
on superstructure	(16 469 kg)	(24 119 kg)	(40 588 kg)
5,500 lbs. (2495 kg) ONLY on carrier	43,746 lbs.	45,734 lbs.	89,480 lbs.
	(19 843 kg)	(20 745 kg)	(40 588 kg)
No cwt. on carrier or superstructure	38,788 lbs.	45,192 lbs.	83,980 lbs.
	(17 594 kg)	(20 499 kg)	(38 093 kg)

TTS870 4 SECTION BOOM ...

Machine equipped as follows:

110 ft. full power 4 section boom 31 - 56 ft. (9.4 - 17 m) folding swingaway Main and auxiliary hoist w/rope Auxiliary boom nose Full fuel and hydraulics 445/65R22.5 front and single rear tires 45 ton hook block (on carrier deck) 10 ton ball (on carrier deck) Counterweight configuration-see chart

AXLE/TIRE CAPACITY	FRONT	REAR	GVW
	49,200 lbs.		98,400 lbs.
	(22 317 kg)	(22 317 kg)	(44 634 kg)

Counterweight placement effects:

8,500 lbs. (3856 kg) cwt.	46,450 lbs.	46,547 lbs.	92,997 lbs.
on superstructure	(21 070 kg)	(21 114 kg)	(42 183 kg)
5,500 lbs. (2495 kg) ONLY	43,746 lbs.	46,251 lbs.	89,997 lbs.
on carrier	(19 843 kg)	(20 979 kg)	(40 823 kg)
No cwt. on carrier or superstructure	38,788 lbs.	45,709 lbs.	84,497 lbs.
	(17 594 kg)	(20 734 kg)	(38 328 kg)

TMS/TTS870 WEIGHT EFFECTS REMOVE:

NT.

REAR

GVW

45 ton hookblock	-1,185 lbs.	+355 lbs.	-830 lbs.
	(-538 kg)	(161 kg)	(-376 kg)
31 - 56 ft. (9.4 - 17 m) swingaway	-1,970 lbs.	-267 lbs.	-2,237 lbs.
	(-894 kg)	(-121 kg)	(-1015 kg)
Auxiliary Nose	-234 lbs.	+107 lbs.	-127 lbs.
	(-106 kg)	(49 kg)	(-58 kg)
10 ton ball	-800 lbs.	+240 lbs.	-560 lbs.
	(-363 kg)	(109 kg)	(-254 kg)

SUBSTITUTE:

FRONT

REAR

GVW

70 ton hookblock w/o cheekplates	+1,205 lbs. (547 kg)	-361 lbs. (-164 kg)	+844 lbs. (383 kg)
31 ft. (9.4 m) swingaway	-417 lbs. (-189 kg)	-264 lbs. (-120 kg)	-681 lbs. (-309 kg)

Note: Weights will vary due to manufacturing tolerances.



TMS870 5 SECTION BOOM

Machine equipped as follows:

138 ft. full power 5 section boom 31 - 56 ft. (9.4 - 17 m) folding swingaway Main and auxiliary hoist w/rope Auxiliary boom nose Full fuel and hydraulics 445/65R22.5 front tires 315/80R22.5 rear tires 45 ton hook block (on carrier deck) 10 ton ball (on carrier deck)

Counterweight configuration-see chart

AXLE/TIRE CAPACITY FRONT 49,200 lbs. 6 (22 317 kg) (2	REAR 60,000 lbs. (27 216 kg)	GVW 109,200 lbs. (49 533 kg)
---	------------------------------------	------------------------------------

Counterweight placement effects:

8,500 lbs. (3856 kg) cwt.	37,739 lbs.	58,701 lbs.	96,440 lbs.
on superstructure	(17 118 kg)	(26 627 kg)	(43 745 kg)
8,500 lbs. (3856 kg) cwt.	49,234 lbs.	47,206 lbs.	96,440 lbs.
on carrier	(22 333 kg)	(21 413 kg)	(43 745 kg)
3,000 lbs. (1361 kg) on S/S	45,177 lbs.	51,263 lbs.	96,440 lbs.
5,500 lbs. (2495 kg) on carrier	(20 492 kg)	(23 253 kg)	(43 745 kg)
5,500 lbs. (2495 kg) on S/S	41,796 lbs.	54,644 lbs.	96,440 lbs.
3,000 lbs. (1361 kg) on carrier	(18 959 kg)	(24 787 kg)	(43 745 kg)
5,500 lbs. (2495 kg) ONLY	39,092 lbs.	54,348 lbs.	93,440 lbs.
on superstructure	(17 732 kg)	(24 652 kg)	(42 384 kg)
5,500 lbs. (2495 kg) ONLY on carrier	46,530 lbs.	46,910 lbs.	93,440 lbs.
	(21 106 kg)	(21 278 kg)	(42 384 kg)
No cwt. on carrier or superstructure	41,572 lbs.	46,368 lbs.	87,940 lbs.
	(18 857 kg)	(21 033 kg)	(39 890 kg)

TTS870 5 SECTION BOOM .

Machine equipped as follows:

138 ft. full power 5 section boom 31 - 56 ft. (9.4 - 17 m) folding swingaway Main and auxiliary hoist w/rope Auxiliary boom nose Full fuel and hydraulics 445/65R22.5 front and single rear tires 45 ton hook block (on carrier deck) 10 ton ball (on carrier deck) Counterweight configuration-see chart

AXLE/TIRE CAPACITY	FRONT	REAR	GVW
	49,200 lbs.	49,200 lbs.	98,400 lbs.
	(22 317 kg)	(22 317 kg)	(44 634 kg)
Counterweight placement effects:			
8,500 lbs. (3856 kg) cwt.	49,031 lbs.	47,665 lbs.	96,696 lbs.
on carrier	(22 240 kg)	(21 621 kg)	(43 861 kg)
5,500 lbs. (2495 kg) ONLY	46,327 lbs.	47,369 lbs.	93,696 lbs.
on carrier	(21 014 kg)	(21 487 kg)	(42 501 kg)
No cwt. on carrier or superstructure	41,369 lbs.	46,827 lbs.	88,196 lbs.
	(18 765 kg)	(21 241 kg)	(40 006 kg)

Note: Weights will vary due to manufacturing tolerances.




BİGGE Tel: (888) 337-BIGGE or (510) 638-8100 • Fax: (510) 639-4053 • Email: info@bigge.com

Rated Lifting Capacities

IMPORTANT NOTES:

WARNING: THIS CHART IS ONLY A GUIDE.
The notes below are for illustration only and should not be relied upon to operate the crane.
The individual crane's load chart, operating instructions and other instruction plates must be read and understood prior to operating the crane.

- 1. All rated loads have been tested to and meet minimum requirements of SAEJ1063 NOV93 Cantilevered Boom Crane Structures Method of Test, and do not exceed 85% of the tipping load on outriggers fully extended as determined by SAEJ765 OCT90 Crane Stability Test Code.
- 2. Capacities given do not include the weight of hook blocks, slings, auxiliary lifting equipment and load handling devices. Their weights MUST be added to the load to be lifted. When more than minimum required reeving is used, the additional rope weight shall be considered part of the load.
- 3. Capacities appearing above the bold line are based on structural strength. Tipping should never be relied upon as a capacity limitation.
- 4. All capacities are for crane on firm, level surface. It may be necessary to have structural supports under the outrigger floats to spread the load to a larger bearing surface.
- 5. When either boom length or radius or both are between values listed, the smallest load shown at either the next larger radius or boom length shall be used.
- 6. For outrigger operation, ALL outriggers shall be properly extended with tires raised free of ground before raising the boom or lifting loads.















Bigge Crane and Rigging Co.

10700 Bigge Avenue San Leandro, CA 94577

Phone: (888) 337-BIGGE or (510) 638-8100

Fax: (510) 639-4053 Email: info@bigge.com Web site: www.bigge.com



Grove Worldwide - World Headquarters Grove North America

1565 Buchanan Trail East P.O. Box 21 Shady Grove, Pennsylvania 17256, U.S.A. Tel: [Int + 1] (717) 597-8121 Fax: [Int + 1] (717) 597-4062 Western Hemisphere, Asia/Pacific

Grove Europe Limited*

Sunderland SR4 6TT, England Tel: [Int + 44] 191 565-6281 Fax: [Int + 44] 191 564-0442 Europe, Africa, Middle East

Grove Europe Limited*

P.O. Box No. 268 4A Kimber Road Abingdon, Oxfordshire, 0X141SG Tel: [Int + 44] 1235 55-3184 Fax: [Int + 44] 1235 55-3218

Deutsche Grove GmbH Sales and Service

Helmholtzstrasse 12, Postfach 5026 D-40750 Langenfeld, Germany Tel: [Int + 49] (2173) 8909-0 Fax: [Int + 49] (2173) 8909-30

Wilhelmshaven Works

Industriegelande West, Postfach 1853 D-26358 Wilhelmshaven, Germany Tel: [Int + 49] (4421) 294-0 Fax: [Int + 49] (4421) 294-301

Grove France S.A.

16, chaussée Jules-César, 95520 OSNY B.P. 203, 95523 CERGY PONTOISE CEDEX Tel: [Int + 33] (1) 30313150

Int: [Int + 33] (1) 30386085

*Grove Europe Limited, Registered in England, Number 1845128, Registered office, Crown Works, Pallion, Sunderland, Tyne & Wear, England SR4 6TT

Grove Asia/Pacific - Regional Office

171 Chin Swee Road #06-01 San Centre Singapore 0316 Tel: [Int + 65] 536-6112 Fax: [Int + 65] 536-6119 Asia/Pacific, Near East

Grove China-Representative Offices

Regional Sales Office Beijing Hotel Room 6074 No. 33 East Chang An Avenue Beijing, 100004, China Tel: [Int + 86] (10) 513-7766 Fax: [Int + 86] (10) 513-7307

Grove Product Support

Western Hemisphere, Asia/Pacific 1086 Wayne Avenue Chambersburg, Pennsylvania USA Tel: [Int + 1] (717) 263-5100 Fax: [Int + 1] (717) 267-0404

Europe, Africa, Middle East Sunderland SR4 6TT, England Tel: [Int + 44] 191 565-6281 Parts Fax: [Int + 44] 191 510-9242 Service Fax: [Int + 44] 191 510-9560

Constant improvement and engineering progress make it necessary that we reserve the right to make specification, equipment, and price changes without notice. Illustrations shown may include optional equipment and accessories and may not include all standard equipment.

Distributed By:

Form No.: TMS/TTS870 Part No.: 3-967 597-10M Printed in U.S.A.

